

Digital Music Player
NWZ-WS613/WS615




Use this manual when you have troubles or when you need to know how to use your WALKMAN®.

The color of Walkman sold in some countries/regions may differ from those shown above.



How to Use

[Getting Started](#)[Basic Operations](#)[Transferring Content](#)[Music](#)[Connecting with a Smartphone](#)[Using with a Smartphone](#)[Announcement](#)[Specifications](#)

Troubleshooting

[Troubleshooting](#)



[Q&A](#)



 [List of Topics](#)

[How to Use](#)



[Troubleshooting](#)



4-536-927-11(1)

Copyright 2014 Sony Corporation

Table Of Contents

NWZ-WS613/WS615 Help Guide.....	i
Getting Started.....	1
Customer registration website.....	58
Before Use.....	18
Enjoying Using Your Walkman.....	19
Parts and Controls.....	20
Power/Charging.....	21
Basic Operations.....	2
How to Place Your Walkman on Your Ears.....	22
LED Lamp.....	23
Using Your Walkman while Swimming.....	24
Using Supplied Remote Commander.....	25
Connecting Your Walkman to Your Computer.....	26
Initializing/Updating.....	27
Transferring Content.....	3
Operation Flow for Transferring Content to Your Walkman.....	28
Installing Media Go.....	29
Installing Content Transfer.....	30
Importing Content to the Software.....	31
Transferring Content to Your Walkman.....	32
Deleting Content from Your Walkman.....	33
Operating with Media Go.....	34
Music.....	4
Playing Music.....	35
Deleting songs.....	141
Connecting with a Smartphone.....	5
Connecting with One Touch (NFC).....	37
Connecting with a Smartphone via Bluetooth Connection.....	38
Notes on the Bluetooth function.....	159
Using with a Smartphone.....	6
Playing Music Stored on a Smartphone.....	40
Answering Incoming Call to a Smartphone.....	41
Selecting the Sound Source between your Walkman and a Smartphone.....	42
Operating Your Walkman Using a Smartphone (SongPal).....	43
Announcement.....	7
Precautions.....	44
Customer support website.....	184
Specifications.....	46

Specifications.....	185
Battery life.....	188
Maximum recordable number of songs and time (Approx.).....	189
Supported formats.....	190
System requirements.....	191
Contents.....	192
Troubleshooting.....	9
What can I do to solve a problem?.....	193
Q&A.....	10
Operation.....	48
Sound.....	49
Power.....	50
Connection to a Computer.....	51
Playing/Deleting Content.....	52
Water Resistant Performance.....	53
Fitting.....	54
Connection to the Smartphone.....	55
Remote Commander.....	56
Other.....	57
How to Use.....	11
Troubleshooting.....	15



Digital Music Player
NWZ-WS613/WS615

Getting Started

[Customer Registration Website](#)



[Before Use](#)



[Enjoying Using Your Walkman](#)



[Parts and Controls](#)



[Power/Charging](#)





Digital Music Player

NWZ-WS613/WS615

Basic Operations

[How to Place Your Walkman on Your Ears](#)[LED Lamp](#)[Using Your Walkman while Swimming](#)[Using Supplied Remote Commander](#)[Connecting Your Walkman to Your Computer](#)[Initializing/Updating](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Transferring Content

[Operation Flow for Transferring Content to Your Walkman](#)[Installing Media Go](#)[Installing Content Transfer](#)[Importing Content to the Software](#)[Transferring Content to Your Walkman](#)[Deleting Content from Your Walkman](#)[Operating with Media Go](#)



How to Use

Digital Music Player
NWZ-WS613/WS615

Music

Playing Music



Deleting Songs





Digital Music Player

NWZ-WS613/WS615

Connecting with a Smartphone

[Connecting with One Touch \(NFC\)](#)[Connecting with a Smartphone via Bluetooth Connection](#)[Notes on the Bluetooth Function](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Using with a Smartphone

[Playing Music Stored on a Smartphone](#)[Answering Incoming Call to a Smartphone](#)[Selecting the Sound Source between your Walkman and a Smartphone](#)[Operating Your Walkman Using a Smartphone \(SongPal\)](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player
NWZ-WS613/WS615

Announcement

[Precautions](#)



[Customer Support Website](#)



4-536-927-11(1)

Copyright 2014 Sony Corporation



How to Use

Digital Music Player

NWZ-WS613/WS615

Specifications

[Specifications](#)



4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Troubleshooting

[What Can I Do to Solve a Problem?](#)



4-536-927-11(1)

Copyright 2014 Sony Corporation

Digital Music Player
NWZ-WS613/WS615

Q&A

Operation



Sound



Power



Connection to a Computer



Playing/Deleting Content



Water Resistant Performance



Fitting



Connection to the Smartphone



Remote Commander



Other





Digital Music Player
NWZ-WS613/WS615

How to Use

Getting Started

Customer Registration Website

- [Customer registration website](#)

Before Use

- [Before first use](#)
- [Walkman instruction manuals](#)

Enjoying Using Your Walkman

- [3 steps to listening to music](#)
- [Various ways to enjoy using your Walkman](#)

Parts and Controls

- [Parts and controls](#)
- [About the differences between the two types of earbuds](#)
- [Changing the earbuds](#)
- [How to store your Walkman in the carrying holder](#)

Power/Charging

- [Turning the power on](#)
- [Turning the power off](#)
- [Charging the battery](#)
- [Extending the battery life](#)
- [Notes on charging the battery](#)

Basic Operations

How to Place Your Walkman on Your Ears

- [How to place your Walkman on your ears](#)
- [Improving the fit](#)
- [Taking your Walkman off](#)

LED Lamp

- [Confirming the Walkman status by the OPR lamp](#)
- [Confirming the Bluetooth status by the Bluetooth lamp](#)

Using Your Walkman while Swimming

- [Water resistant performance of this Walkman](#)

- [Liquids that the water resistant performance specifications apply to](#)
- [Changing the earbuds to Swimming earbuds](#)
- [How the sound becomes muffled while you are swimming](#)
- [If the sound becomes muffled while swimming](#)
- [Notes while swimming](#)
- [Notes on charging the battery after swimming](#)

Using Supplied Remote Commander

- [Parts and controls of the Remote Commander](#)
- [Using the Remote Commander](#)
- [Replacing the battery of the Remote Commander](#)
- [Notes on using the Remote Commander](#)

Connecting Your Walkman to Your Computer

- [Connecting to a computer](#)
- [Notes on connecting your Walkman to a computer](#)

Initializing/Updating

- [Resetting your Walkman](#)
- [Resetting to the factory settings](#)
- [Formatting memory](#)
- [Updating the system software of your Walkman](#)
- [Displaying your Walkman information](#)

Transferring Content

Operation Flow for Transferring Content to Your Walkman

- [Preparing content using a Windows computer](#)
- [Preparing content using a Mac computer](#)

Installing Media Go

- [About Media Go](#)
- [Installing Media Go](#)

Installing Content Transfer

- [About Content Transfer](#)
- [Installing Content Transfer](#)

Importing Content to the Software

- [Importing content from media using Media Go](#)
- [Importing content on your Windows computer into Media Go](#)
- [Importing podcasts into Media Go](#)

Transferring Content to Your Walkman

- [Transferring content using Media Go](#)
- [Transferring iTunes content using Media Go](#)
- [Transferring content using Content Transfer](#)
- [Transferring content using Explorer](#)
- [Transferring content using the Finder](#)

- [Notes for transferring content such as music from your computer](#)

Deleting Content from Your Walkman

- [Deleting content from your Walkman using Media Go](#)
- [Deleting content from your Walkman using Content Transfer](#)
- [Deleting content from your Walkman using Explorer](#)
- [Deleting content from your Walkman using the Finder](#)

Operating with Media Go

- [Deleting content imported to Media Go](#)

Music

Playing Music

- [Preparing music](#)
- [Playing music](#)
- [Volume operation \(Only for countries/areas complying with European and Korean Directives\)](#)
- [Adjusting the volume](#)
- [Skipping to the previous/next song](#)
- [Skipping to the previous/next folder/playlist/album](#)
- [Shuffle playback](#)
- [Repeat playback](#)
- [Changing the playback order to Folder Play/Playlist Play/Album Play](#)
- [Limiting the volume](#)

Deleting Songs

- [Deleting songs](#)

Connecting with a Smartphone

Connecting with One Touch (NFC)

- [What is the NFC function?](#)
- [Requirements for smartphones connecting with your Walkman by one touch \(NFC\)](#)
- [About “NFC Easy Connect”](#)
- [Installing the “NFC Easy Connect” app on an Android smartphone](#)
- [Connecting with a smartphone by the NFC function](#)
- [Disconnecting with the smartphone by the NFC function](#)

Connecting with a Smartphone via Bluetooth Connection

- [What is the Bluetooth function?](#)
- [Turning the Bluetooth function on/off](#)
- [Pairing and connecting with an Android smartphone](#)
- [Connecting with a paired smartphone](#)
- [Pairing and connecting with an iPhone](#)
- [Setting wireless playback quality](#)
- [Confirming the Bluetooth status by the Bluetooth lamp](#)

Notes on the Bluetooth Function

Using with a Smartphone

Playing Music Stored on a Smartphone

- [Playing music on a smartphone](#)

Answering Incoming Call to a Smartphone

- [Answering/hanging up a call](#)
- [Rejecting an incoming call](#)
- [Volume for calls on smartphones](#)

Selecting the Sound Source between your Walkman and a Smartphone

- [Selecting the sound source](#)
- [Using “Sound Mix”](#)

Operating Your Walkman Using a Smartphone (SongPal)

- [What is SongPal?](#)
- [Installing SongPal on a smartphone](#)
- [Using SongPal](#)
- [Home screen of SongPal](#)
- [Drawer of SongPal](#)
- [Playing music on your Walkman by SongPal](#)
- [Changing the playback mode of your Walkman from SongPal](#)
- [Customizing the settings of your Walkman from SongPal](#)

Announcement

Precautions

- [Notes on handling your Walkman](#)
- [Notes on headphones](#)
- [Notes on the software](#)
- [Notes while swimming](#)
- [Notes on charging the battery after swimming](#)
- [Maintenance of your Walkman](#)

Customer Support Website

- [Customer support website](#)

Specifications

Specifications

- [Specifications](#)
- [Battery life](#)
- [Maximum recordable number of songs and time \(Approx.\)](#)
- [Supported formats](#)
- [System requirements](#)
- [Contents](#)

Digital Music Player
NWZ-WS613/WS615

Troubleshooting

Troubleshooting

What Can I Do to Solve a Problem?

- [What can I do to solve a problem?](#)
- [Customer support website](#)

Q&A

Operation

- [Your Walkman does not operate or the power does not turn on.](#)
- [Your Walkman does not work properly.](#)
- [Your Walkman power turns off or on automatically.](#)
- [A drink \(water, coffee, etc.\) was spilled on your Walkman, or the Walkman was washed in the washing machine.](#)
- [The earbuds supplied with the headphones are missing.](#)
- [You want to back up the content such as music stored on your Walkman.](#)
- [You want to find the product name \(model name\) of your Walkman.](#)
- [The voice guidance "Check the volume level" is heard.](#)

Sound

- [There is no sound.](#)
- [Content such as music suddenly stops during playback.](#)
- [Noise is generated.](#)
- [Volume cannot be turned up, or the volume remains low when the playback volume is turned up.](#)
- [Sound is interrupted or skips.](#)

Power

- [You cannot charge your Walkman.](#)
- [How long is the life of the built-in rechargeable battery?](#)
- [The rechargeable battery needs to be replaced.](#)
- [The battery life is short.](#)
- [How long is the standard battery duration?](#)
- [How long does it take to charge the battery?](#)

Connection to a Computer

- [The computer does not recognize your Walkman.](#)
- [You cannot install software to your computer.](#)
- [The progress bar on the install screen does not proceed while installing the software.](#)

- Your Walkman is not recognized by Media Go.
- Content such as music cannot be transferred from the computer to your Walkman.
- Only a small amount of content such as music can be transferred to your Walkman.

Playing/Deleting Content

- You cannot play content such as music transferred to your Walkman.
- Content such as music suddenly stops during playback.
- Songs are not played back in the expected order.

Water Resistant Performance

- Sound becomes muffled when using your Walkman in water, such as when swimming.
- You dropped your Walkman in water.

Fitting

- The headphones are not firmly seated on your ears.
- The neckband part does not fit.
- The earbuds do not fit.

Connection to the Smartphone

- Pairing cannot be done.
- You cannot connect via the Bluetooth function.
- The screen to enter the passkey appears when pairing with a smartphone.
- Sound skips or noise is generated during a Bluetooth connection.
- You cannot connect with one touch (NFC).
- You cannot hear sound from the connected smartphone.
- You cannot take incoming calls properly.

Remote Commander

- You cannot operate your Walkman by the Remote Commander.

Other

- Your Walkman gets warm.



Digital Music Player

NWZ-WS613/WS615

Customer Registration Website

[Customer registration website](#)

View information on websites where you can register your Walkman.



4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Before Use

[Before first use](#)

Be sure to read this manual before you use your Walkman for the first time.



[Walkman instruction manuals](#)

There are a wide variety of instruction manuals available in addition to this Help Guide.



4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Enjoying Using Your Walkman

[3 steps to listening to music](#)



This section explains how you can start enjoying using your Walkman after purchase in three simple steps.

[Various ways to enjoy using your Walkman](#)



Your Walkman can do more than simply play back music. Get to know more about various ways you can enjoy using the Walkman.

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Parts and Controls

[Parts and controls](#)

This section introduces the functions of buttons, jacks, and other parts of your Walkman.



[About the differences between the two types of earbuds](#)

This section explains the characteristics of the two different types of earbuds.



[Changing the earbuds](#)

You can change the earbuds if the initially installed earbuds do not fit your ears correctly.



[How to store your Walkman in the carrying holder](#)

This section explains how to use the carrying holder (supplied).





Digital Music Player

NWZ-WS613/WS615

Power/Charging

[Turning the power on](#)



Turn on the power to start your Walkman.

[Turning the power off](#)



Turn off the power when not using your Walkman.

[Charging the battery](#)



Charge your Walkman by connecting it to a computer.

[Extending the battery life](#)



This section introduces various ways to reduce battery consumption such as frequently turning the power off and changing various settings.

[Notes on charging the battery](#)



This section contains various notes about charging your Walkman.



Digital Music Player

NWZ-WS613/WS615

How to Place Your Walkman on Your Ears

[How to place your Walkman on your ears](#)

Place your Walkman on your ears and adjust it to fit you.



[Improving the fit](#)

This section explains how to fit your Walkman better on your ears.



[Taking your Walkman off](#)

Instructions and notes for when you take your Walkman off your ears are explained.



4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player
NWZ-WS613/WS615

LED Lamp

[Confirming the Walkman status by the OPR lamp](#)



The OPR lamp indicates the condition of the battery or settings by changing color and blinking patterns.

[Confirming the Bluetooth status by the Bluetooth lamp](#)



The Bluetooth lamp indicates the status of the Bluetooth connection by changing color and blinking speed.

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Using Your Walkman while Swimming

[Water resistant performance of this Walkman](#)



This section explains the water resistant performance of your Walkman.

[Liquids that the water resistant performance specifications apply to](#)



This section explains the types of liquid that the water resistant specifications of your Walkman apply to.

[Changing the earbuds to Swimming earbuds](#)



You can change the earbuds if the initially installed earbuds do not fit your ears correctly while swimming.

[How the sound becomes muffled while you are swimming](#)



This section explains the cases where the sound becomes muffled while swimming and how to prevent those from happening.

[If the sound becomes muffled while swimming](#)



This section explains how to remove water from your ears and headphone sections.

[Notes while swimming](#)



This section contains notes for using your Walkman while swimming.

[Notes on charging the battery after swimming](#)



Important notes for charging the battery after swimming are explained.



Digital Music Player

NWZ-WS613/WS615

Using Supplied Remote Commander

[Parts and controls of the Remote Commander](#)



This section explains the functions of buttons and other parts of the Remote Commander (supplied).

[Using the Remote Commander](#)



Use the Remote Commander (supplied) to operate your Walkman wirelessly.

[Replacing the battery of the Remote Commander](#)



This section explains how to replace the battery of the Remote Commander (supplied).

[Notes on using the Remote Commander](#)



Important notes for using the Remote Commander (supplied) are explained.



Digital Music Player

NWZ-WS613/WS615

Connecting Your Walkman to Your Computer

[Connecting to a computer](#)

Connect your Walkman to a computer via USB to charge the Walkman or transfer data.



[Notes on connecting your Walkman to a computer](#)

This section contains notes on connecting your Walkman to a computer.



4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Initializing/Updating

[Resetting your Walkman](#)

Reset your Walkman if operations become unstable.



[Resetting to the factory settings](#)

Reset your Walkman to the default settings.



[Formatting memory](#)

Initialize your Walkman by formatting the memory.



[Updating the system software of your Walkman](#)

Add new features to your Walkman by installing the latest system software.



[Displaying your Walkman information](#)

Display information on your Walkman, such as the model name and system software version.





Digital Music Player

NWZ-WS613/WS615

Operation Flow for Transferring Content to Your Walkman

[Preparing content using a Windows computer](#)

Installing Media Go (built into the memory of your Walkman) enables you to import CDs, download and manage content from online music services, and transfer them to the Walkman.



[Preparing content using a Mac computer](#)

Installing Content Transfer (built into the memory of your Walkman) enables you to transfer content to the Walkman.



4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Installing Media Go

About Media Go

Media Go is software that allows you to import various content to your Windows computer, manage the content and transfer it to your Walkman. 

Installing Media Go

Connect your Walkman to your Windows computer and install Media Go. 

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Installing Content Transfer

[About Content Transfer](#)

Content Transfer is software that allows you to transfer content managed with iTunes or the Finder to your Walkman.

[Installing Content Transfer](#)

Connect your Walkman to your Mac computer and install Content Transfer.

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Importing Content to the Software

[Importing content from media using Media Go](#)



This section explains how to import music from CDs by using Media Go.

[Importing content on your Windows computer into Media Go](#)



You can organize a wide range of content such as music, photos and videos that you have already imported to your Windows computer using other software together using Media Go.

[Importing podcasts into Media Go](#)



Media Go has a wide range of podcast functions, and you can use Media Go to manage your podcast subscriptions.

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Transferring Content to Your Walkman

[Transferring content using Media Go](#)



Use Media Go to transfer content or playlists that are also managed on your computer to your Walkman.

[Transferring iTunes content using Media Go](#)



Use Media Go to transfer content or playlists on your computer or managed with iTunes to your Walkman.

[Transferring content using Content Transfer](#)



Use Content Transfer to transfer content or playlists on your Mac computer or managed with iTunes to your Walkman.

[Transferring content using Explorer](#)



Use drag-and-drop in Windows Explorer to directly transfer content to your Walkman.

[Transferring content using the Finder](#)



Use drag-and-drop in the Finder to directly transfer content to your Walkman.

[Notes for transferring content such as music from your computer](#)



When transferring files and folders to your Walkman by drag-and-drop, you need to make sure that the default folder names remain unchanged and the hierarchy is correct.



Digital Music Player

NWZ-WS613/WS615

Deleting Content from Your Walkman

[Deleting content from your Walkman using Media Go](#)

Use Media Go to delete content stored on your Walkman.



[Deleting content from your Walkman using Content Transfer](#)

Use Content Transfer to delete content stored on your Walkman.



[Deleting content from your Walkman using Explorer](#)

Use Windows Explorer to delete content stored on your Walkman.



[Deleting content from your Walkman using the Finder](#)

Use the Finder to delete content stored on your Walkman.





Digital Music Player

NWZ-WS613/WS615

Operating with Media Go

[Deleting content imported to Media Go](#)

Use Media Go to delete content imported to Media Go.



4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Playing Music

Preparing music

You need to transfer music from your computer to your Walkman in order to listen to music on the Walkman.

Playing music

Play music that you transferred from your computer to your Walkman.

Volume operation (Only for countries/areas complying with European and Korean Directives)

The voice guidance “Check the volume level” is meant to protect your ears when you turn the volume up to a level that is harmful for your ears for the first time.

Adjusting the volume

Adjust the volume using the VOL + and - button. The volume can be adjusted in 31 steps: from 0 to 30. “10” is set by default.

Skipping to the previous/next song

Skip to the previous/next song.

Skipping to the previous/next folder/playlist/album

Skip to the beginning of the previous or next folder quickly.

Shuffle playback

Play songs in random order.

Repeat playback

Play songs repeatedly.

Changing the playback order to Folder Play/Playlist Play/Album Play

You can change the playback order to Folder Play/Playlist Play/Album Play.

Limiting the volume

You can use AVLS (Automatic Volume Limiter System) to limit the maximum volume.



Digital Music Player

NWZ-WS613/WS615

Deleting Songs

Deleting songs

Delete songs transferred to your Walkman.



4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Connecting with One Touch (NFC)

[What is the NFC function?](#)

This function enables easy data communication between various devices, such as mobile phones and IC tags, simply by touching the devices together.

[Requirements for smartphones connecting with your Walkman by one touch \(NFC\)](#)

Requirements for a smartphone to be connected with your Walkman by the NFC function are shown.

[About “NFC Easy Connect”](#)

The “NFC Easy Connect” app allows your smartphone to connect easily with the NFC-compatible devices manufactured by Sony.

[Installing the “NFC Easy Connect” app on an Android smartphone](#)

Install the “NFC Easy Connect” app on your Android smartphone.

[Connecting with a smartphone by the NFC function](#)

Touch your NFC-compatible smartphone to your Walkman to make a Bluetooth connection.

[Disconnecting with the smartphone by the NFC function](#)

Disconnect the connection between your Walkman and the smartphone by one touch.



Digital Music Player

NWZ-WS613/WS615

Connecting with a Smartphone via Bluetooth Connection

[What is the Bluetooth function?](#)

The Bluetooth function is based on short-range wireless technology used in devices such as headphones and mini stereo music systems to connect digital devices.



[Turning the Bluetooth function on/off](#)

Turn on the Bluetooth function when connecting your Walkman with a smartphone.



[Pairing and connecting with an Android smartphone](#)

Pair your Walkman and your smartphone when you connect them for the first time via Bluetooth connection.



[Connecting with a paired smartphone](#)

Connect a paired smartphone and your Walkman.



[Pairing and connecting with an iPhone](#)

Pair your Walkman and your iPhone when you connect them for the first time via Bluetooth connection.



[Setting wireless playback quality](#)

You can set whether to prioritize the sound quality or the stability of the connection during a Bluetooth connection.



[Confirming the Bluetooth status by the Bluetooth lamp](#)

The Bluetooth lamp indicates the status of the Bluetooth connection by changing color and blinking speed.





Digital Music Player

NWZ-WS613/WS615

Notes on the Bluetooth Function

[Notes on the Bluetooth function](#)

This section contains notes for using Bluetooth connections.



4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Playing Music Stored on a Smartphone

[Playing music on a smartphone](#)

Play music stored on your smartphone.



4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Answering Incoming Call to a Smartphone

[Answering/hanging up a call](#)

You can answer and hang up a phone call to your smartphone that is connected to your Walkman via the active Bluetooth connection.



[Rejecting an incoming call](#)

When your Walkman is connected to your smartphone, you can reject an incoming call with the Walkman.



[Volume for calls on smartphones](#)

The volume for music and the volume for calls are independent from each other.



4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Selecting the Sound Source between your Walkman and a Smartphone

Selecting the sound source

When your Walkman is connected to a Bluetooth audio device, you can select the sound source setting from between Walkman Mode and Headphones Mode.



Using “Sound Mix”

When your Walkman is in Walkman Mode, “Sound Mix” allows you to listen to sound from smartphone applications and the Walkman at the same time.



4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Operating Your Walkman Using a Smartphone (SongPal)

[What is SongPal?](#)

SongPal allows you to control your Walkman from your smartphone.



[Installing SongPal on a smartphone](#)

Download and install SongPal on your smartphone or iPhone to control your Walkman.



[Using SongPal](#)

Use SongPal to control your Walkman from your smartphone.



[Home screen of SongPal](#)

This section explains how to view the Home screen of SongPal.



[Drawer of SongPal](#)

This section explains how to view Drawer of SongPal.



[Playing music on your Walkman by SongPal](#)

Use SongPal to play music on your Walkman using your smartphone.



[Changing the playback mode of your Walkman from SongPal](#)

Use SongPal to change the playback mode of your Walkman from your smartphone.



[Customizing the settings of your Walkman from SongPal](#)

Customize various settings of your Walkman using SongPal.





Digital Music Player

NWZ-WS613/WS615

Precautions

[Notes on handling your Walkman](#)

Important information for using your Walkman is explained.



[Notes on headphones](#)

Important notes for the headphones are explained.



[Notes on the software](#)

Important notes for the software are explained.



[Notes while swimming](#)

This section contains notes for using your Walkman while swimming.



[Notes on charging the battery after swimming](#)

Important notes for charging the battery after swimming are explained.



[Maintenance of your Walkman](#)

Important notes for cleaning your Walkman are explained.





Digital Music Player

NWZ-WS613/WS615

Customer Support Website

[Customer support website](#)

Visit the customer support website if you have any questions or issues with your Walkman.



4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Specifications

Specifications

Details on the Walkman specifications (size, weight, and memory size, etc.) are shown.



Battery life

The estimated battery usage time based on typical usage conditions and settings are explained.



Maximum recordable number of songs and time (Approx.)

The maximum recordable number of songs and time are explained.



Supported formats

The file formats that are supported by your Walkman are explained.



System requirements

Details on the system requirements needed to use your Walkman (the operating system version and memory size, etc.) are shown.



Contents

A list of accessories and manuals supplied with your Walkman is shown.





Digital Music Player

NWZ-WS613/WS615

What Can I Do to Solve a Problem?

[What can I do to solve a problem?](#)

This section contains solutions for when your Walkman does not function as expected or if a problem occurs during operation.



[Customer support website](#)

Visit the customer support website if you have any questions or issues with your Walkman.



4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Operation

Your Walkman does not operate or the power does not turn on.



Your Walkman does not work properly.



Your Walkman power turns off or on automatically.



A drink (water, coffee, etc.) was spilled on your Walkman, or the Walkman was washed in the washing machine.



The earbuds supplied with the headphones are missing.



You want to back up the content such as music stored on your Walkman.



You want to find the product name (model name) of your Walkman.



The voice guidance “Check the volume level” is heard.





Digital Music Player

NWZ-WS613/WS615

Sound

There is no sound.



Content such as music suddenly stops during playback.



Noise is generated.



Volume cannot be turned up, or the volume remains low when the playback volume is turned up.



Sound is interrupted or skips.



4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Power

[You cannot charge your Walkman.](#)[How long is the life of the built-in rechargeable battery?](#)[The rechargeable battery needs to be replaced.](#)[The battery life is short.](#)[How long is the standard battery duration?](#)[How long does it take to charge the battery?](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Connection to a Computer

The computer does not recognize your Walkman.



You cannot install software to your computer.



The progress bar on the install screen does not proceed while installing the software.



Your Walkman is not recognized by Media Go.



Content such as music cannot be transferred from the computer to your Walkman.



Only a small amount of content such as music can be transferred to your Walkman.





Digital Music Player

NWZ-WS613/WS615

Playing/Deleting Content

You cannot play content such as music transferred to your Walkman.



Content such as music suddenly stops during playback.



Songs are not played back in the expected order.



4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Water Resistant Performance

Sound becomes muffled when using your Walkman in water, such as when swimming.



You dropped your Walkman in water.



4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Fitting

The headphones are not firmly seated on your ears.



The neckband part does not fit.



The earbuds do not fit.



4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Connection to the Smartphone

Pairing cannot be done.



You cannot connect via the Bluetooth function.



The screen to enter the passkey appears when pairing with a smartphone.



Sound skips or noise is generated during a Bluetooth connection.



You cannot connect with one touch (NFC).



You cannot hear sound from the connected smartphone.



You cannot take incoming calls properly.





Digital Music Player

NWZ-WS613/WS615

Remote Commander

You cannot operate your Walkman by the Remote Commander.



4-536-927-11(1)

Copyright 2014 Sony Corporation



Troubleshooting

Digital Music Player

NWZ-WS613/WS615

Other

[Your Walkman gets warm.](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player
NWZ-WS613/WS615

Customer registration website

We recommend that you register your Walkman so we can provide better customer support. Visit one of the following websites to register the Walkman.

For customers in the USA:

<http://www.sony.com/walkmanreg/>

For customers in Canada:

English

<http://www.Sony.ca/Registration>

French

<http://www.Sony.ca/Enregistrement>

For customers in Latin America:

<http://www.sony-latin.com/registration>

For customers in Europe:

<http://walkman.sony-europe.com/usb-registration>

For customers in Asia/Oceania/Middle East/Africa:

English/Korean/Traditional Chinese

<http://www.sony-asia.com/dmpwalkman/register/>

Simplified Chinese

https://www.sonystyle.com.cn/b2c_sony/b2c/productRegister.do



Digital Music Player

NWZ-WS613/WS615

Before first use

Thank you for purchasing this Walkman.

This “Help Guide” explains how to transfer content to your Walkman, and how to use the various functions. Browse this “Help Guide” for necessary information.

The printed manuals (supplied), such as “Quick Start Guide,” also contain important information for you. For information about the customer support website, see “Customer support website.”

- For information on laws, regulations and trademark rights, refer to “Important Information” contained in the supplied software. To read it, install the supplied software on your computer.
- All other trademarks and registered trademarks are trademarks or registered trademarks of their respective holders. In this manual, TM and ® marks are not specified.

About model names mentioned in this “Help Guide”

Depending on the country/region in which you have purchased your Walkman, some models may not be available.

Computer system requirements when connecting the Walkman

See “System requirements” for details on computer system requirements.

Battery charging

The battery might be low when you use your Walkman for the first time. Charge the battery before using the Walkman.

About images used in this “Help Guide”

The illustrations shown are for reference only and may differ from the actual product.

Design and specifications are subject to change without notice.

Related Topic

- [System requirements](#)
- [Customer support website](#)
- [Charging the battery](#)



Digital Music Player
NWZ-WS613/WS615

Walkman instruction manuals

The operations of this Walkman are explained in the following instruction manuals.

Quick Start Guide (paper)

Describes the basic operating instructions (provided only in some languages).

Help Guide

You are currently viewing the Help Guide. This contains information such as explanations of Walkman operations and software.

Important Information

Contains information on trademark rights, laws, and regulations. You can read it by installing the software (supplied) on your computer.

4-536-927-11(1)


Copyright 2014 Sony Corporation



Digital Music Player
NWZ-WS613/WS615

3 steps to listening to music

Be sure to charge the battery before you use your Walkman for the first time. You can transfer music while charging the battery. You can listen to your music as soon as the transfer has completed.



1. Connect your Walkman to a computer.

You can charge the battery by connecting your Walkman via a USB connection to a computer that is turned on and running.

2. Import music to your computer and transfer the music to your Walkman.

For Windows users

- Recommended: Install Media Go, which is pre-installed in the built-in memory of your Walkman.
You can transfer music that you have imported from CDs or downloaded from online music services to your Walkman.
- You can transfer music by drag-and-drop directly from Windows Explorer to your Walkman.

For Mac users

- Recommended: Install Content Transfer, which is pre-installed in the built-in memory of your Walkman.
You can transfer music and playlists that are managed with iTunes to your Walkman by an easy operation.
- You can transfer music by drag-and-drop directly from the Finder to your Walkman.

3. Enjoy your music!

Turn on your Walkman, put it on, and start playing the music you want to listen to!

Related Topic

- [Charging the battery](#)

- Installing Media Go
- Importing content from media using Media Go
- Transferring content using Media Go
- Transferring iTunes content using Media Go
- Installing Content Transfer
- Transferring content using Content Transfer
- Transferring content using Explorer
- Transferring content using the Finder
- Turning the power on
- Playing music

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Various ways to enjoy using your Walkman

Your Walkman can do more than simply play back music. Get to know more about various ways you can enjoy using the Walkman.

Using your Walkman while swimming

Change the earbuds to the Swimming earbuds and enjoy using your Walkman even while swimming.

Operating your Walkman with the Remote Commander

The Remote Commander and the Walkman are already paired at the factory, so just turn them on and they are ready to use without pairing.

Using with a smartphone

You can enjoy listening to music on your smartphone using your Walkman. You can also use the Walkman to answer incoming calls to your smartphone.

“Sound Mix” allows you to listen to sound from a smartphone application and the Walkman at the same time. You can also use SongPal, a smartphone application that allows you to operate the Walkman using your smartphone.

Related Topic


- [Changing the earbuds to Swimming earbuds](#)
- [Using the Remote Commander](#)
- [Playing music on a smartphone](#)



Digital Music Player NWZ-WS613/WS615

Parts and controls

This section explains the functions of buttons, jacks, and other parts of your Walkman.



1. Tactile dot

There is a tactile dot on the left part of your Walkman. Use it to distinguish left from right when you operate it.

2. Neckband

3. Earbud

4. Headphone section

5. Bluetooth lamp

6. (Bluetooth) button

Press and hold for 2 seconds to turn the Bluetooth function on or off.

Press and hold for 7 seconds while the Bluetooth function is turned off to pair with a Bluetooth device.

7. VOL (Volume) + (*1)/- button

Press to adjust the music playback, ringtone, and call volumes.

8. MODE button

Press to switch the playback mode (All Song/Repeat/Shuffle).

Press and hold for longer than 1 second to switch the playback order (Folder/Playlist/Album).

9. Terminals

10. (Play) button (*1)

Press to start/pause playback or to answer/hang up a call.

Press and hold for 2 seconds to switch the sound source (Walkman/Bluetooth device) or to reject an incoming call.

Press and hold for 15 seconds to enter the formatting mode.

11. RESET button

Press the RESET button with a pen or a paper clip, etc., to reset your Walkman.

12. OPR (Operation) lamp
13.  (Power) button
Press and hold for 3 seconds to turn your Walkman on or off.
14.  (Previous) button
Press to skip to the previous song.
Press and hold for longer than 2 seconds to skip to the beginning of the previous folder.
15.  (Next) button
Press to skip to the next song.
Press and hold for longer than 2 seconds to skip to the beginning of the next folder.
16. Built-in Bluetooth antenna
Do not cover the antenna part with your hands or other object when a Bluetooth connection is active. Doing so may interrupt the connection.
17. N-mark
Touch a Bluetooth device equipped with an NFC function to this mark to connect it to your Walkman.
18. Built-in microphone
Do not cover the microphone part with your hands or other object when you talk on your Walkman. Doing so may block your voice sound.

(*1) There is a tactile dot. Use it to help with button operations.

Related Topic

- [Turning the power on](#)
- [Turning the power off](#)
- [Confirming the Walkman status by the OPR lamp](#)
- [Confirming the Bluetooth status by the Bluetooth lamp](#)
- [Resetting your Walkman](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

About the differences between the two types of earbuds

There are two different types of earbuds (supplied): standard-type and swimming type. The characteristics of each type are as follows.

- Standard-type earbuds:
You can use them in a wide variety of situations.
- Swimming earbuds:
Employing a structure that prevents water penetration inside the headphones, Swimming earbuds allow you to enjoy music more comfortably while swimming.

Note

- The sound volume is lower with Swimming earbuds than with standard-type earbuds. Increase the volume as needed.
- When you replace Swimming earbuds with the standard-type earbuds, the sound becomes louder. Adjust the volume so as not to hurt your eardrums.

Related Topic

- [Changing the earbuds](#)
- [Changing the earbuds to Swimming earbuds](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player
NWZ-WS613/WS615

Changing the earbuds



To enjoy better sound quality, change the earbuds (supplied) to another size to fit your ears comfortably and snugly.

1. While holding the headphone, twist and pull the earbud off.
If the earbud slips and cannot be detached, wrap it in a soft dry cloth.



2. Attach the earbuds to the headphone.

Push the earbud onto the headphone to where the end of the earbud's colored part (1) aligns with 2. Attach the earbud firmly to the headphones to prevent it from detaching and remaining in your ear.



Hint

- If the earbuds become worn, purchase new earbuds.
- If the earbuds get dirty, remove the earbuds from the headphones and hand-wash them with neutral detergent. After washing, drain off the water and reattach them.

Related Topic

- [Changing the earbuds to Swimming earbuds](#)


4-536-927-11(1)

Copyright 2014 Sony Corporation

Digital Music Player
NWZ-WS613/WS615

How to store your Walkman in the carrying holder

Whenever carrying or when not using your Walkman, store your Walkman in the carrying holder (supplied).



1. Turn off your Walkman.
2. Attach your Walkman to the carrying holder firmly.
3. Rotate your Walkman inward toward the carrying holder until the Walkman sets in place.

4-536-927-11(1)


Copyright 2014 Sony Corporation



Digital Music Player NWZ-WS613/WS615

Turning the power on

Turn on the power to start your Walkman.



1. Press and hold the button ([1]) on the right ([R]) side of your Walkman for 3 seconds.
Your Walkman turns on and a startup sound will be heard. The lamp ([2]) on the right ([R]) side of your Walkman blinks in orange quickly while the Walkman is turned on.

Hint

- If there is no operation for an extended period, the lamp ([2]) turns off and your Walkman will be turned off automatically. In that case, press and hold the button ([1]) to turn on the Walkman.

Related Topic

- [Turning the power off](#)
- [Confirming the Walkman status by the OPR lamp](#)




Digital Music Player

NWZ-WS613/WS615

Turning the power off

Turn off the power when not using your Walkman.



1. Press and hold the button ([1]) on the right ([R]) side of your Walkman for 3 seconds.
After the beep sound and the voice guidance “Power Off” is heard, the lamp ([2]) on the right ([R]) side of your Walkman and your Walkman turns off.

Hint

- If there is no operation for an extended period, your Walkman will be turned off automatically.

Related Topic


- [Turning the power on](#)
- [Confirming the Walkman status by the OPR lamp](#)



Digital Music Player
NWZ-WS613/WS615

Charging the battery

Charge your Walkman by connecting it to a computer.



1. Attach your Walkman to the USB cradle in the order of the left (L) part first, then the right (R) part. Make sure that the terminals of your Walkman (1) and the USB cradle (2) are in contact with each other.
2. Connect your Walkman to a running computer via USB.
The lamp (3) on the right (R) side of your Walkman lights up in orange while charging the battery. Charging is complete when the lamp (3) turns off.
3. Disconnect your Walkman from the computer when charging is complete.

Hint

- The Remote Commander cannot be charged. For details on how to replace the battery of the Remote Commander, see "Replacing the battery of the Remote Commander."
- For information about the time to fully charge the battery, see "Specifications."

Note

- When you charge your Walkman when it has not been used for a long period of time or when you use it for the first

time, your computer may not recognize it. The Walkman should start operating normally again after charging for about 10 minutes.

- Dry and clean the terminals of your Walkman using a soft dry cloth, if the terminals are wet or dirty.
- You cannot operate your Walkman when it is connected to a computer.
- You cannot operate your Walkman while charging the battery.

Related Topic

- [Connecting to a computer](#)
- [Confirming the Walkman status by the OPR lamp](#)
- [Extending the battery life](#)
- [Notes on charging the battery](#)
- [Specifications](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Extending the battery life

You can reduce battery consumption by using your Walkman as follows.

For a comparison of battery life based on set effects, default settings and functions, see “Battery life.”

- Turn off the power manually.
- Set all sound quality settings to off.
- Turn off the Bluetooth function when not in use.

Related Topic

- [Turning the power off](#)
- [Turning the Bluetooth function on/off](#)
- [Customizing the settings of your Walkman from SongPal](#)
- [Battery life](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Notes on charging the battery

- The charging time differs depending on the battery usage conditions.
- If the battery life is reduced to about half of its normal life even if sufficiently charged, it has probably worn out. Please contact your nearest Sony dealer.
- If you charge your Walkman when it has not been used for a long period of time, your computer may not recognize it, or the Walkman may not respond. Charge the Walkman for about 10 minutes, after which it should start operating normally again.
- Charge the battery in an ambient temperature between 5 °C to 35 °C (41 °F to 95 °F).
- The number of times the battery can be recharged from complete discharge is approximately 500 times. This number may vary depending on the conditions under which you use your Walkman.
- To prevent battery deterioration, charge the battery at least once every six months to one year.
- Charging is not guaranteed with homebuilt or modified computers.
- Operation with a USB port extended with a USB hub is only guaranteed when a self-powered USB hub that carries an authorized logo is used.
- Do not leave your Walkman connected for an extended period of time to a laptop computer that is not connected to an AC power supply. Doing so may discharge the computer's battery.
- Do not turn on, restart, wake up from sleep mode, or shut down the computer with your Walkman connected to the computer via USB. Doing so may cause the Walkman to malfunction. Disconnect the Walkman from the computer before conducting these operations.
- Your Walkman may become hot while charging. This is not a malfunction.
- You cannot operate your Walkman when it is connected to a computer.
- You cannot operate your Walkman while charging the battery.

4-536-927-11(1)

Copyright 2014 Sony Corporation




Digital Music Player

NWZ-WS613/WS615

How to place your Walkman on your ears

Choose the size of earbud that fits into your left/right ear each. If you find that the earbuds easily come off, try another size that fits into your ears.



1. Check the left (L) and right (R) parts of your Walkman.
2. Press and hold the button (1) on the right (R) side of your Walkman for about 3 seconds to turn on the Walkman.
3. Hang the neckband over the top of your ears and behind your head.
4. Place the headphone sections into your ears.
5. Adjust your Walkman so it feels comfortable.

Hint

- If your Walkman does not feel comfortable, replace the earbuds.
- To use your Walkman for swimming, change the earbuds to Swimming earbuds.

Note

- Fit your Walkman earbuds into your ears before swimming while the earbuds and your ears are still dry.
- Make sure to fit your Walkman earbuds into your ears firmly so that water does not get into your ears through a gap between your ears and the headphones.

Related Topic

- [Improving the fit](#)
- [Taking your Walkman off](#)




Digital Music Player
NWZ-WS613/WS615

Improving the fit

Try the following to fit your Walkman better on your ears.


Stabilizing your Walkman with the adjustment band (supplied)

You can place your Walkman earbuds more firmly into your ears by using the adjustment band.



Stabilizing your Walkman with swimming goggles

By stabilizing the part on your Walkman indicated by the arrow using the band of your swimming goggles, you can prevent your Walkman from detaching because of water pressure.



Note

- Do not use strong force to deform or bend the neckband. If you bend the neckband at the same part repeatedly, it may break. If it breaks, a wire-like metal may project from the covering and you could injure yourself. If the neckband breaks, stop using your Walkman.

- [How to place your Walkman on your ears](#)

- [Taking your Walkman off](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation




Digital Music Player

NWZ-WS613/WS615

Taking your Walkman off

When you take your Walkman off your ears, be sure to follow the instructions and notes below.

1. Gently move your Walkman up and down to take it off your ears.

**Note**

- Removing the Walkman suddenly when the earbuds are fitted firmly in your ears may cause damage to your ears or eardrums, or the earbuds may remain in your ears.

Related Topic

- [How to place your Walkman on your ears](#)
- [Improving the fit](#)

4-536-927-11(1)


Copyright 2014 Sony Corporation



Digital Music Player
NWZ-WS613/WS615

Confirming the Walkman status by the OPR lamp

The OPR lamp (1) on the right (R) side of your Walkman indicates the condition of the battery or settings by changing color and blinking patterns.



When you turn on your Walkman

Starting up

● → 🌞 → ● (Lights up in green, blinks in orange and then stays lit in green)

Your Walkman is ready to use when the lamp (1) turns green after blinking in orange.

An error has occurred

● (Lights up in red for 10 seconds)

Turn the power off and then back on.

During playback or pause

Battery has been charged enough

● (Lights up or blinks in green)

Current remaining battery power is low

● and 🌞 (Blinks in green and orange alternately)

Battery is discharged

🌞 and ● (Blinks in orange and red alternately)

The battery has no charge left. Your Walkman beeps and then becomes inoperable.

Music is not played back due to an error

💥 (Blinks in red twice)

While connected to a computer

Battery is being charged

 (Lights up in orange)

Battery has been fully charged

 (Goes out)

Accessing the Walkman via a USB connection, such as when data is being transferred

 (Blinks in orange quickly)

You are trying to charge the battery in an ambient temperature outside the range of 5 °C (41 °F) to 35 °C (95 °F)

 (Blinks in red twice)


Related Topic
 Confirming the Bluetooth status by the Bluetooth lamp



Digital Music Player
NWZ-WS613/WS615

Confirming the Bluetooth status by the Bluetooth lamp

The Bluetooth lamp (1) on the left (L) side of your Walkman indicates the status of the Bluetooth connection by changing color and blinking speed.



Bluetooth function turned on

 (Blinks in blue twice)

Pairing in progress

 and  (Blinks in blue and red quickly alternately)

Your Walkman is in the process of pairing with a Bluetooth device.

Operating a connection

 (Blinks in blue twice every second)

If Bluetooth devices are paired, when you turn on the Bluetooth function of your Walkman, the Walkman makes the Bluetooth connection with the last connected device automatically.

Bluetooth connection active (Connection was successful)

 (Blinks in blue once, twice or 3 times every 5 seconds)

The number of blinks differs depending on the types of the connected Bluetooth devices, status of playback or call, etc.

Bluetooth function turned off

 →  (Lights up in blue for 2 seconds and then goes out)

Related Topic

- [Confirming the Walkman status by the OPR lamp](#)



Digital Music Player

NWZ-WS613/WS615

Water resistant performance of this Walkman

The water resistant specifications (*1) of this Walkman are equivalent to IEC 60529 “Degrees of protection against ingress of water (IP Code)” IPX5/8 (*2), which specifies the degree of protection provided against the entry of water. If you use your Walkman in a swimming pool, do not exceed a depth of 2 meters (6.5 feet) while wearing it. Before use, be sure to read and understand the water resistant specifications completely.

(*1) The headphone sections are not water-tight.

(*2) IPX5 (Degrees of protection against jets of water): Your Walkman, with Swimming earbuds attached, will maintain its operability even when exposed to direct streams of water from any direction in a situation where approximately 12.5 l/min. of water is supplied for more than 3 minutes from a distance of about 3 meters using a nozzle with an inner diameter of 6.3 millimeters. However, this does not apply to the headphone sections.

IPX8 (Degrees of protection against continual water submersion): Your Walkman, with Swimming earbuds attached, will maintain its operability even when submersed in water to a depth of 2 meters for 30 minutes.

Related Topic

- [Changing the earbuds to Swimming earbuds](#)
- [How the sound becomes muffled while you are swimming](#)
- [If the sound becomes muffled while swimming](#)
- [Notes while swimming](#)
- [Notes on charging the battery after swimming](#)



Digital Music Player

NWZ-WS613/WS615

Liquids that the water resistant performance specifications apply to

The types of liquid that the water resistant specifications of your Walkman apply to are as follows.

Applicable:

Fresh water, tap water, perspiration, pool water

Not applicable:

Liquids other than those above (examples: soapy water, detergent water, water with bath agents, shampoo, hot spring water, salt water, etc.)

The water resistant performance of your Walkman is based on our measurements under the conditions described above. Note that malfunctions as a result of water immersion caused by misuse by the customer are not covered by the warranty.

Related Topic

- [Changing the earbuds to Swimming earbuds](#)
- [How the sound becomes muffled while you are swimming](#)
- [If the sound becomes muffled while swimming](#)
- [Notes while swimming](#)
- [Notes on charging the battery after swimming](#)




Digital Music Player
NWZ-WS613/WS615

Changing the earbuds to Swimming earbuds

To enjoy using your Walkman while swimming, change the earbuds to another type/size to fit your ears comfortably and snugly.

1. Select the appropriate Swimming earbuds.

The standard-type earbuds are attached when you purchase your Walkman.



The standard-type earbud has an open hole (1).

The Swimming earbud has a hole covered with a thin film (2) to make it difficult for water to get in.

2. Choose the best fitting Swimming earbuds.


There are 4 different sizes of Swimming earbuds (S/M/L/LL) (supplied).

Choose a size slightly tighter than the standard-type.


Your ears may require different sized earbuds as not all ears are the same. For example: left side medium size, right side large size.

3. Attach Swimming earbuds to your Walkman.

Install the earbuds onto the headphones so that the tip of the inner part (3) of the earbuds fits into the position (4) on the projection of the headphones.



Make sure that the earbuds fit straight on, not at an angle, to prevent the earbuds from detaching and remaining in your ears.



Related Topic

- [Water resistant performance of this Walkman](#)
- [Liquids that the water resistant performance specifications apply to](#)
- [About the differences between the two types of earbuds](#)

4-536-927-11(1)


Copyright 2014 Sony Corporation



How the sound becomes muffled while you are swimming

The sound may become muffled in cases like those shown below.

- When water gets into a gap between your ears and the headphones ([1]) and covers the eardrum ([2]):
You can prevent water penetration by using the most appropriate size of earbuds that fit your ears firmly.
- When water accumulates in the drivers of the headphones ([3]):
You can prevent water penetration by using the Swimming earbuds (supplied).



Related Topic

- [Water resistant performance of this Walkman](#)
- [Liquids that the water resistant performance specifications apply to](#)
- [About the differences between the two types of earbuds](#)



Digital Music Player
NWZ-WS613/WS615

If the sound becomes muffled while swimming

Water inside your ears or headphones may cause the sound to be muffled.



Removing water from your ears

Remove water from your ears.



Removing water from headphones

When water gets inside the headphones (1), remove the earbuds from the headphones and pat the headphones lightly 5 to 10 times on a dry cloth.



Related Topic

- [Water resistant performance of this Walkman](#)
- [Liquids that the water resistant performance specifications apply to](#)
- [About the differences between the two types of earbuds](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Notes while swimming

- Do not use your Walkman in places where an inability to hear surrounding sound would be dangerous.
- When you use your Walkman in public or private swimming facilities, follow the rules of that facility.
- Do not use your Walkman while swimming in a river or in the ocean.
- Your Walkman cannot be connected to your smartphone.
- You cannot use the Remote Commander (supplied).
- The earbuds (supplied) seal your ears. Therefore, be aware that there is a risk of damage to your ears or eardrums if strong pressure is applied to the earbuds or the earbuds are removed suddenly from your ears. Due to this risk, do not do vigorous exercises, dive into a swimming pool, etc., while wearing your Walkman.
- Do not pour hot water directly on your Walkman and do not blow hot air from a hair dryer, etc., directly on the Walkman. Never use the Walkman in high-temperature locations such as in saunas or near a stove.
- The sound volume is lower with Swimming earbuds than with standard-type earbuds. Increase the volume as needed.
- When you replace Swimming earbuds with the standard-type earbuds, the sound becomes louder. Adjust the volume so as not to hurt your eardrums.

Related Topic

- [Water resistant performance of this Walkman](#)
- [Liquids that the water resistant performance specifications apply to](#)
- [About the differences between the two types of earbuds](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Notes on charging the battery after swimming

- The USB cradle (supplied) is not water resistant.
- Before charging the battery, make sure your Walkman is not wet.
- If there is moisture on your Walkman, wipe it off completely, and leave the Walkman at room temperature to dry until no moisture remains on the Walkman before you start charging.
- Never use the USB cradle with wet hands or when your Walkman is wet.

Related Topic

- [Water resistant performance of this Walkman](#)
- [Liquids that the water resistant performance specifications apply to](#)
- [About the differences between the two types of earbuds](#)


4-536-927-11(1)

Copyright 2014 Sony Corporation



Parts and controls of the Remote Commander

This section explains the functions of buttons and other parts of the Remote Commander (supplied).



1. VOL (Volume) +/- button

Press to adjust the music playback, ringtone, and call volumes.

2. button (*1)

Press to start/pause playback or to answer/hang up a call.

Press and hold for 2 seconds to turn on the Remote Commander or to reject an incoming call.

3. Lamp (blue/red)

4. (Previous) button

Press to skip to the previous song.

Press and hold for longer than 2 seconds to skip to the beginning of the previous folder.

5. (Next) button

Press to skip to the next song.

Press and hold for longer than 2 seconds to skip to the beginning of the next folder.

6. Antenna (aerial)

The antenna is built-in. Do not cover the antenna part with your hands or other object when using the Remote Commander. Doing so may interrupt the connection.

7. Band

8. Band loop

When you press any button, the lamp lights up. If it does not light up, the battery is depleted or the Remote Commander is turned off.

(*1) There is a tactile dot. Use it to help with button operations.

Related Topic

[Using the Remote Commander](#)




Digital Music Player

NWZ-WS613/WS615

Using the Remote Commander

The Remote Commander (supplied) allows you to operate your Walkman wirelessly. The Remote Commander and the Walkman are already paired at the factory, so just turn them on and they are ready to use without pairing.

The power of your Walkman has to be turned on before performing the procedures below.



1. Put the Remote Commander on your finger.



If the band does not fit the size of your finger, remove the Remote Commander once and adjust the band, then put it on again.

2. Check that your Walkman is turned on.

3. Turn on the Remote Commander.

Press and hold the button (1) for more than 2 seconds. When the Remote Commander is turned on, the lamp (2) starts blinking. Your Walkman and the Remote Commander are automatically connected to each other and the lamp (2) turns off.

Skip this step if the lamp (2) lights up when you press any of the Remote Commander buttons. The Remote Commander is already turned on.

4. Press the desired button of the Remote Commander to operate your Walkman.

Hint

- The Remote Commander is automatically turned off when your Walkman is turned off.
- The Remote Commander is automatically turned off if you do not operate it for more than 2 hours.
- If the remaining battery power is low, the lamp ([2]) color changes to red.
- You cannot turn on or off your Walkman by the Remote Commander.
- To delete pairing information, press and hold the buttons ([3] and [4]) for about 10 seconds.
- If the Remote Commander has no pairing information, it will be in pairing mode automatically when it is turned on.

Related Topic

- [Parts and controls of the Remote Commander](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation




Digital Music Player

NWZ-WS613/WS615


Replacing the battery of the Remote Commander

Replace the battery of the Remote Commander (supplied) when the lamp color changes to red. Be sure to use a CR1620 Lithium Coin Cell Battery only.

When you open the battery cover, the waterproof performance may be impaired by dust, etc. To maintain waterproof performance, consult your nearest Sony dealer or Sony Service Center for replacement of the battery (at extra cost).



1. Make sure that the Remote Commander is turned off. Remove the band ([1]) from the loop ([4]).
2. Use a size 0 cross-head precision screwdriver and remove the screws ([2], 4 in total).
3. Open the cover ([3]), remove the battery, and insert a new CR1620 battery with correct polarity.
4. Check that the packing ([5]) is in place and is clean.
5. Put the cover ([3]) back into place and tighten the screws ([2]) firmly to the end.
Do not overtighten the screws ([2]).
6. Reattach the band ([1]) back through the loop ([4]).
7. Press the button ([6]) on the left ([L]) side of your Walkman for about 7 seconds and turn the Remote Commander on.
Pairing starts and the lamp ([7]) on the left ([L]) side of your Walkman blinks in blue and red. When the pairing is completed, the lamp ([7]) blinks in blue.



Note

- Do not lose the cover ([3]) and screws ([2]).
- The battery supplied at the time of purchase may have a shorter battery life as it is installed at the factory to check the performance.

4-536-927-11(1)

Copyright 2014 Sony Corporation



Notes on using the Remote Commander

- The water resistant specifications of this Remote Commander (supplied) are equivalent to IEC 60529 “Degrees of protection against ingress of water (IP Code)” IPX5 (*1), which specifies the degree of protection provided against the entry of water.
- You cannot use the Remote Commander in a swimming pool.
- You cannot use the Remote Commander when it is wet.
- The antenna (aerial) is built into the Remote Commander.
- The following conditions may cause the Remote Commander to become inoperable.
 - When using in an area with a wireless LAN, in an area where devices such as microwave ovens, mobile phones and mobile gaming devices with a communication function are in use nearby, or in other areas where electromagnetic waves are being emitted.
 - When the antenna (aerial) built into the Remote Commander is covered by your hand or blocked by people in situations such as riding in a crowded train.
- If tanning oil or sunscreen gets onto the Remote Commander, wash it off using lukewarm water. Otherwise, it may cause discoloration or damage such as cracks to occur.


(*1) IPX5 (Degrees of protection against jets of water): The Remote Commander will maintain its operability even when exposed to direct streams of water from any direction in a situation where approximately 12.5 l/min. of water is supplied for more than 3 minutes from a distance of about 3 meters using a nozzle with an inner diameter of 6.3 millimeters.



Digital Music Player
NWZ-WS613/WS615

Connecting to a computer

Connect your Walkman to a computer via USB to charge the Walkman or transfer data.



1. Attach your Walkman to the USB cradle in the order of the left (L) part first, then the right (R) part. Make sure that the terminals of your Walkman (1) and of the USB cradle (2) are in contact with each other.
2. Connect your Walkman to a running computer via USB.

Note

- When you connect your Walkman to the USB cradle (2), dry the terminals of your Walkman (1) using a soft dry cloth.
- You cannot operate your Walkman when it is connected to a computer.

Hint

- If you are prompted to make a Windows operation, click "Cancel" or "x."

Related Topic

- [Notes on connecting your Walkman to a computer](#)

- [Transferring content using Media Go](#)
- [Transferring content using Content Transfer](#)
- [Charging the battery](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Notes on connecting your Walkman to a computer

- Your Walkman cannot be operated when connected to a computer.
- Do not disconnect your Walkman from your computer when transferring data between the Walkman and the computer via USB. Doing so may result in loss of the data being transferred and data on the Walkman.
- Do not turn on, restart, wake up from sleep mode, or shut down the computer with your Walkman connected to the computer via USB. Doing so may cause the Walkman to malfunction. Disconnect the Walkman from the computer before conducting those operations.

4-536-927-11(1)


Copyright 2014 Sony Corporation



Digital Music Player
NWZ-WS613/WS615

Resetting your Walkman

Try resetting your Walkman if operations become unstable. Before resetting the Walkman, disconnect the Walkman from your computer and check that no content such as music is being played. Otherwise, the data may be damaged.



1. Press the button (1) on the right (R) side of your Walkman with a pen or a paper clip, etc. to reset your Walkman.

Note

- Resetting your Walkman will not delete any data or reset any settings.

Related Topic


- [Resetting to the factory settings](#)
- [Formatting memory](#)
- [Confirming the Walkman status by the OPR lamp](#)
- [Using the Remote Commander](#)
- [Customer support website](#)



Digital Music Player
NWZ-WS613/WS615

Resetting to the factory settings

Your Walkman can be reset to the default settings. Resetting the Walkman will not delete content such as music. If you reset your Walkman, the pairing information of the Remote Commander and the other Bluetooth devices is deleted.



1. Check that the playback is paused and the Bluetooth function is turned off.
2. Press and hold the Next button ([1]) on the right (R) side of your Walkman for 15 seconds while pressing the button ([2]) on the left (L) side of your Walkman.
When resetting is completed, the lamp ([3]) on the right (R) side of your Walkman blinks in green twice.

Note

- To pair your Walkman to the Remote Commander again, press the button ([4]) on the left (L) side of your Walkman for 7 seconds and turn the Remote Commander on. Pairing starts and the lamp ([5]) on the left (L) side of your Walkman blinks in blue and red. When the pairing is completed, the lamp ([5]) blinks in blue.

Related Topic


- [Resetting your Walkman](#)
- [Formatting memory](#)
- [Confirming the Walkman status by the OPR lamp](#)



Digital Music Player
NWZ-WS613/WS615

Formatting memory

You can initialize your Walkman by formatting the memory.



1. Check that the playback is paused and the Bluetooth function is turned off.
2. Press and hold the button ([1]) on the right (R) side of your Walkman for about 15 seconds until the lamp ([2]) on the right (R) side of your Walkman blinks in orange quickly.
3. Release the button ([1]).
The lamp ([2]) lights up in red.
4. Press the Previous/Next button ([3]) on the right (R) side of your Walkman within 30 seconds after the lamp ([2]) lights up in red.
5. Press the button ([1]) while the lamp ([2]) is lit in green.
The lamp ([2]) blinks in green quickly while formatting. The lamp ([2]) turns off when formatting is completed.

Note

- Be sure not to initialize (format) the memory of your Walkman using a computer. If you have formatted it with a computer, format it again using the Walkman.
- Formatting the memory erases all content data (songs, etc., including the sample data installed at the factory, the supplied software installer, and the “Help Guide”). Be sure to check the data stored in the memory and export any important data to your computer before formatting.

Related Topic

- [Resetting your Walkman](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Updating the system software of your Walkman

You can add new features to your Walkman by installing the latest system software. For details on the latest system software information and how to install it, visit the customer support website for your area.

1. Download the update program to your computer from the website.
2. Connect your Walkman to your computer and start the update program.
3. Follow the on-screen instructions to update the system software of your Walkman.

Hint

- You can check the system software version of your Walkman by connecting the Walkman to your computer. Check the “information.txt” file in the [WALKMAN] folder on your computer. The “information.txt” file contains the following information.
 - 01: Model name
 - 02: Memory capacity
 - 03: System software version

Related Topic

- [Customer support website](#)
- [Connecting to a computer](#)
- [Displaying your Walkman information](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Displaying your Walkman information

Check information such as model name, memory capacity, and system software version.

1. Connect your Walkman to a running computer via USB.
2. Open the “WALKMAN” folder using the procedure below that corresponds to your computer.
 - Windows 7 or earlier:
Select “Start” – “Computer,” and open the “WALKMAN” folder.
 - Windows 8:
Select “Desktop” from the “Start screen” to open “File Explorer.” In the “Computer” list, open the “WALKMAN” folder.
 - Windows 8.1: Select “Desktop” to open “File Explorer.” In the “This PC” list, open the “WALKMAN” folder.
 - Mac:
Select “WALKMAN” in the sidebar of the Finder.
3. Check the “information.txt” file.
The “information.txt” file contains the following information.
 - 01: Model name
 - 02: Memory capacity
 - 03: System software version

Related Topic

● [Connecting to a computer](#)



Digital Music Player

NWZ-WS613/WS615

Preparing content using a Windows computer

Installing Media Go (built into the memory of your Walkman) enables you to import CDs, download and manage content from online music services, and transfer them to the Walkman.

1. Install Media Go (built into the memory of your Walkman) on your Windows computer.
2. Import content to Media Go.
You can import music, photos or videos on media or your Windows computer to Media Go.
3. Transfer the content to your Walkman.
Transfer the imported content from Media Go to your Walkman.

Hint

- You can also transfer content directly from Windows Explorer to your Walkman by drag-and-drop.

Related Topic

- [About Media Go](#)
- [Installing Media Go](#)
- [Importing content from media using Media Go](#)
- [Importing content on your Windows computer into Media Go](#)
- [Importing podcasts into Media Go](#)
- [Transferring content using Media Go](#)
- [Transferring iTunes content using Media Go](#)
- [Transferring content using Explorer](#)
- [Notes for transferring content such as music from your computer](#)
- [Deleting content from your Walkman using Media Go](#)
- [Deleting content from your Walkman using Explorer](#)



Preparing content using a Mac computer

Installing Content Transfer (built into the memory of your Walkman) enables you to transfer content to the Walkman.

1. Install Content Transfer (built into the memory of your Walkman) on your Mac computer.
2. Drag-and-drop the content on your Mac computer to Content Transfer.
The content is transferred to your Walkman.

Hint

- You can also transfer content directly from iTunes or the Finder to your Walkman by drag-and-drop.

Related Topic

- [About Content Transfer](#)
- [Installing Content Transfer](#)
- [Transferring content using Content Transfer](#)
- [Transferring content using the Finder](#)
- [Notes for transferring content such as music from your computer](#)
- [Deleting content from your Walkman using the Finder](#)



Digital Music Player

NWZ-WS613/WS615

About Media Go

Media Go is software for your Windows computer that allows you to import various content such as music, photos or videos to your Windows computer and manage stored content on your Windows computer. You can transfer content that you have imported from CDs or downloaded from online music services to your Walkman. If you have already managed content such as music with iTunes, etc., you can use Media Go to transfer the content to the Walkman.

Related Topic

- [Installing Media Go](#)
- [Importing content from media using Media Go](#)
- [Transferring content using Media Go](#)
- [Transferring iTunes content using Media Go](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Installing Media Go

Install Media Go to your Windows computer.

1. Connect your Walkman to your Windows computer via USB.
2. Open the “WALKMAN” folder using the procedure below that corresponds to your computer.
 - Windows 7 or earlier:
Select “Start” – “Computer,” and open the “WALKMAN” folder.
 - Windows 8:
Select “Desktop” from the “Start screen” to open “File Explorer.” In the “Computer” list, open the “WALKMAN” folder.
 - Windows 8.1:
Select “Desktop” to open “File Explorer.” In the “This PC” list, open the “WALKMAN” folder.
3. Double-click “FOR_WINDOWS.”
4. Double-click “MediaGo_WM(.exe)” in the folder.
The setup file is extracted.
Depending on the version of Windows, a “User Account Control” screen may appear. In this case, click “Yes.”
5. Follow the on-screen instructions to install Media Go.
When you click “Finish” after installation, Media Go automatically starts.

Hint

- During installation, you may be prompted to install additional software components that are necessary to run Media Go. If prompted, follow the on-screen instructions to download and install the components.
- When your Windows computer is connected to the Internet, the latest version of Media Go is automatically searched and downloaded. If a message to install the latest version of Media Go appears, click the message and follow the on-screen instructions to install the software.

Note

- Depending on the environment, restarting your computer may be required. Follow the on-screen instructions.

Related Topic

● [Connecting to a computer](#)

- [About Media Go](#)
- [Importing content from media using Media Go](#)
- [Transferring content using Media Go](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

About Content Transfer

Content Transfer is software for your Mac computer that allows you to transfer content such as music, photos or videos managed with iTunes or the Finder to your Walkman easily. You can transfer files, folders, and playlists to the appropriate folder of the Walkman simply by drag-and-drop.

Related Topic

- [Installing Content Transfer](#)
- [Transferring content using Content Transfer](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Installing Content Transfer

Install Content Transfer to your Mac computer.

1. Connect your Walkman to your Mac computer via USB.
2. Select “WALKMAN” in the sidebar of the Finder.
3. Double-click the “FOR_MAC” folder.
4. Double-click “ContentTransfer.pkg.”
The installer starts.
5. Follow the on-screen instructions to install Content Transfer.
 is displayed in the Dock when the installation is completed. Click  to start Content Transfer.

Related Topic

- [Connecting to a computer](#)
- [About Content Transfer](#)
- [Transferring content using Content Transfer](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Importing content from media using Media Go

Use Media Go to import content such as music on your Windows computer. This section explains how to import music from CDs. Your computer must be connected to the Internet to obtain CD information such as song names and artist names automatically.



1. Start up Media Go and insert an audio CD into the CD drive of your Windows computer.
Media Go detects the CD and displays a window for CD information. When Media Go obtains the CD information (CD title, song name, artist name, etc.), it is displayed in this window.
2. Click “Import CD” (1).
Wait until all content such as music has been imported.

Hint

- For details about how to use Media Go, refer to the help of Media Go.
- Recommended file formats for ripping CDs are AAC (.mp4) and MP3 (.mp3) for normal sound quality. Music in these formats can be transferred to your Walkman more effectively.
- Media Go obtains the CD information from a database on the Internet. Information on some CDs may not be available in the database. If information on your CD is missing, you can add it manually after importing the CD. For information about adding and editing CD information, refer to the help of Media Go.

Note

- Imported content is limited to private use only. Use of content for other purposes requires the permission of the copyright holders.
- Commercial DVDs and Blu-ray discs cannot be imported into Media Go.

- [Installing Media Go](#)
- [Transferring content using Media Go](#)

4-536-927-11(1)


Copyright 2014 Sony Corporation



Digital Music Player
NWZ-WS613/WS615

Importing content on your Windows computer into Media Go

Import content such as music imported to your Windows computer into Media Go.



1. Start Media Go.
2. Select the type of content you want to import from "Library."
3. Drag-and-drop the content into the Content List area.

Hint

- You can also import data organized by programs such as iTunes by selecting "File" - "Add/Remove Media from Library" in Media Go. For details, refer to the help of Media Go.

Note

- Copy-protected videos cannot be imported into Media Go.
- Some video formats cannot be imported or played.

Related Topic

- [Transferring content using Media Go](#)



Digital Music Player

NWZ-WS613/WS615

Importing podcasts into Media Go

Media Go has a wide range of podcast functions on Windows, and you can use Media Go to manage your podcast subscriptions. The podcast directory is also convenient for finding the latest content or content you are interested in. For details on importing podcasts, refer to the help of Media Go.

4-536-927-11(1)


Copyright 2014 Sony Corporation



Digital Music Player
NWZ-WS613/WS615

Transferring content using Media Go

Transfer content such as music or playlists managed with Media Go on your computer to your Walkman. Content with copyright protection cannot be transferred.



1. Connect your Walkman to a running computer via USB, and then start Media Go.
2. Select the desired content ([1]) on Music Library of Media Go, and drag-and-drop it to your "WALKMAN (model name)" ([2]).
Media Go recognizes the type of data by the filename extension and sends it to the appropriate folder of your Walkman.

Note

- Media Go does not support content that uses Windows Media digital rights management technology ("WM-DRM").

Related Topic


- [Connecting to a computer](#)
- [Importing content from media using Media Go](#)
- [Importing content on your Windows computer into Media Go](#)



Digital Music Player
NWZ-WS613/WS615

Transferring iTunes content using Media Go

Media Go supports transfer of data from iTunes to your Walkman. Transfer content such as music or playlists managed with iTunes on your computer to the Walkman. Content with copyright protection cannot be transferred.



1. Connect your Walkman to a running computer via USB, and then start Media Go.
2. Start iTunes.
3. Select the desired content from iTunes ([1](#)), and drag-and-drop it to your "Walkman (model name)" ([2](#)).
Media Go recognizes the type of data by the filename extension and sends it to the appropriate folder of your Walkman.

Related Topic


 [Connecting to a computer](#)



Digital Music Player
NWZ-WS613/WS615

Transferring content using Content Transfer

Transfer content such as music or playlists on your Mac computer or managed with iTunes to your Walkman. Content with copyright protection cannot be transferred.



1. Connect your Walkman to a running computer via USB, and then start Content Transfer.
2. Display the desired content on the Finder or the desired content or playlists on iTunes.
3. Drag-and-drop the content or playlists you want to transfer to Content Transfer.
Content is transferred to your Walkman.


Related Topic

● [Connecting to a computer](#)

Digital Music Player
NWZ-WS613/WS615

Transferring content using Explorer

Content such as music can be directly transferred by drag-and-drop using Windows Explorer.



1. Connect your Walkman to a running computer via USB.
2. Open the "WALKMAN" folder using the procedure below that corresponds to your computer.
 - Windows 7 or earlier:
Select "Start" – "Computer," and then open the "WALKMAN" folder.
 - Windows 8:
Select "Desktop" from the "Start screen" to open "File Explorer." In the "Computer" list, open the "WALKMAN" folder.
 - Windows 8.1:
Select "Desktop" to open "File Explorer." In the "This PC" list, open the "WALKMAN" folder.
3. Open the folder to which you want to transfer content.
To transfer music files or folders: "MUSIC" folder
4. Drag-and-drop the desired files or folders ([1]) to the applicable folder ([2]) in the "WALKMAN" folder.

Note

- You cannot operate your Walkman when it is connected to a computer.
- Do not change folder name or delete the "MUSIC" folder.
- Some songs may not be played back on your Walkman due to copyright protection.

Related Topic

- [Connecting to a computer](#)
- [Notes for transferring content such as music from your computer](#)

4-536-927-11(1)


Copyright 2014 Sony Corporation



Digital Music Player
NWZ-WS613/WS615

Transferring content using the Finder

Content such as music can be directly transferred by drag-and-drop using the Finder.



1. Connect your Walkman to a running computer via USB.
2. Select "WALKMAN" in the sidebar of the Finder.
3. Open the folder to which you want to transfer content.
To transfer music files or folders: "MUSIC" folder
4. Drag-and-drop the desired files or folders ([1]) to the applicable folder ([2]) in the "WALKMAN" folder.

Note

- You cannot operate your Walkman when it is connected to a computer.
- Do not change folder name or delete the "MUSIC" folder.
- Some songs may not be played back on your Walkman due to copyright protection.
- Do not disconnect your Walkman while the OPR lamp is blinking. Otherwise, data being transferred or stored on the Walkman may be damaged. If the Walkman is disconnected while files are being transferred, unnecessary files may be left in the Walkman. In this case, transfer usable files back to the computer and format the Walkman.

Related Topic

- [Connecting to a computer](#)
- [Notes for transferring content such as music from your computer](#)




Digital Music Player

NWZ-WS613/WS615

Notes for transferring content such as music from your computer

Drag-and-drop content such as music or folders into the correct folder as shown in the following illustrations. Your Walkman can play back content stored in the 1st to 8th level of each folder.



Note

- Do not rename the following default folders.
 - MUSICOtherwise, they will not be recognized by your Walkman anymore.
- Copyright protected files that were transferred to your Walkman using drag-and-drop cannot be played on the Walkman.



Digital Music Player

NWZ-WS613/WS615

Deleting content from your Walkman using Media Go

You can use Media Go to delete content stored on your Walkman.

1. Connect your Walkman to a running computer via USB.
2. Start Media Go.
3. Double-click “WALKMAN (model name)” and select the type of content you want to delete.
The content list is displayed.
4. Select the content you want to delete.
5. Click “Edit” - “Delete.”
A window to confirm the deletion of the item is displayed.
6. Click “Yes.”

Related Topic

- [Connecting to a computer](#)
- [Transferring content using Media Go](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Deleting content from your Walkman using Content Transfer

You can use Content Transfer to delete content stored on your Walkman.

1. Connect your Walkman to a running computer via USB.
2. Start Content Transfer.
3. Click  at the right bottom of the screen.
4. Click the icon of the folder (such as "Music") that contains the content you want to delete.
The content list is displayed.
5. Select the content you want to delete.
6. Click "Delete."
The selected content is deleted.

Related Topic

- [Connecting to a computer](#)
- [Transferring content using Content Transfer](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Deleting content from your Walkman using Explorer

Delete content stored on your Walkman using Windows Explorer.

1. Connect your Walkman to a running computer via USB.
2. Open the "WALKMAN" folder using the procedure below that corresponds to your computer.
 - Windows 7 or earlier:
Select "Start" - "Computer," and open the "WALKMAN" folder.
 - Windows 8:
Select "Desktop" from the "Start screen" to open "File Explorer." In the "Computer" list, open the "WALKMAN" folder.
 - Windows 8.1:
Select "Desktop" to open "File Explorer." In the "This PC" list, open the "WALKMAN" folder.
3. Open the folder containing the file(s) you want to delete.
To delete a music file or a folder that contains music: "MUSIC" folder
4. Select the content you want to delete.
5. Delete the content.

Note

- Do not change folder name or delete the "MUSIC" folder.

Related Topic

- [Connecting to a computer](#)
- [Transferring content using Explorer](#)



Digital Music Player

NWZ-WS613/WS615

Deleting content from your Walkman using the Finder

Delete content stored on your Walkman using the Mac Finder.

1. Connect your Walkman to a running computer via USB.
2. Open a folder under “WALKMAN” from the sidebar of the Finder.
3. Open the folder containing the file(s) you want to delete.
To delete a music file or a folder that contains music: “MUSIC” folder
4. Select the content you want to delete.
5. Delete the content.

Note

- Do not change folder name or delete the “MUSIC” folder.

Related Topic

- [Connecting to a computer](#)
- [Transferring content using the Finder](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Deleting content imported to Media Go

You can delete content imported to Media Go.

1. Start Media Go.
2. Select the type of content you want to delete from “Library.”
The content list is displayed.
3. Select the content you want to delete.
4. Click “Edit” - “Delete.”
A “Confirm Delete” window is displayed.
5. Select a method to delete the content.
6. Click “OK.”

Related Topic

● [Deleting content from your Walkman using Media Go](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Preparing music

You need to transfer music from your computer to your Walkman in order to listen to music on the Walkman. After importing songs from a CD or your computer to Media Go, use Media Go to transfer them to the Walkman. You can also transfer them by drag-and-drop from Windows Explorer. For a Mac computer, you can use Content Transfer to transfer the songs from iTunes, etc. You can also transfer them by drag-and-drop from the Mac Finder.


Related Topic

- [Connecting to a computer](#)
- [Importing content from media using Media Go](#)
- [Importing content on your Windows computer into Media Go](#)
- [Transferring content using Media Go](#)
- [Transferring content using Content Transfer](#)
- [Transferring content using Explorer](#)
- [Transferring content using the Finder](#)
- [Notes for transferring content such as music from your computer](#)



Playing music

Play music transferred to your Walkman.



1. Press the button (1) on the right (R) side of your Walkman.
Press the button (1) again to pause playback.

Hint

- When playback of the last song is finished, your Walkman automatically restarts playback from the first song and continues in sequential order.

Note

- If there is no operation for an extended period while paused, the lamp (2) on the right (R) side of your Walkman turns off and your Walkman will be turned off automatically. In that case, press and hold the button (3) on the right (R) side of your Walkman to turn it back on, and then press the button (1) to start playback music.
- Depending on the way of transferring songs to your Walkman, songs might be played in different order from the song order on your computer. When you specify a song order other than that on your Walkman, edit the playlists with a function of Media Go or iTunes, and then transfer them to your Walkman.

Related Topic

- [Preparing music](#)
- [Skipping to the previous/next song](#)
- [Skipping to the previous/next folder/playlist/album](#)
- [Shuffle playback](#)
- [Repeat playback](#)
- [Changing the playback order to Folder Play/Playlist Play/Album Play](#)

- [Playing music on a smartphone](#)
- [Setting wireless playback quality](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation

Digital Music Player
NWZ-WS613/WS615

Volume operation (Only for countries/areas complying with European and Korean Directives)

The voice guidance “Check the volume level” is meant to protect your ears when you turn the volume up to a level that is harmful for your ears for the first time. You can cancel the alarm and warning by pressing any button.

Note

- You can turn up the volume after canceling the alarm and warning.
- After the initial warning, the alarm and warning repeat every 20 cumulative hours that the volume is set to a level that is harmful for your ears. When this happens, the volume is turned down automatically.
- If the volume is set to a level that is harmful for your ears and you turn off the Walkman, the volume is turned down to a level that is safe for your ears automatically.
- The alarm (beep) does not sound when your Walkman is in Headphones Mode.

Related Topic


● [Adjusting the volume](#)



Digital Music Player
NWZ-WS613/WS615

Adjusting the volume

Adjust the volume with the VOL + and - button.



1. Adjust the volume with the button (**1** or **2**) on the left (**L**) side of your Walkman.

Hint

- There is a tactile dot on the button (**1**).

Note

- If you turn off your Walkman with the volume set to “0,” the volume will be automatically set to “1” when you start playback next time.

Related Topic


- [Limiting the volume](#)
- [Playing music](#)



Digital Music Player
NWZ-WS613/WS615

Skipping to the previous/next song

Skip to the previous/next song.



1. Press the Previous/Next button (**1** or **2**) on the right (**R**) side of your Walkman to skip to the previous/next song.
The previous (or current) or next song starts.

Related Topic


- [Playing music](#)
- [Skipping to the previous/next folder/playlist/album](#)



Digital Music Player
NWZ-WS613/WS615

Skipping to the previous/next folder/playlist/album

Skip to the beginning of the previous or next folder/playlist/album quickly.



1. Press and hold the Previous/Next button (**1** or **2**) on the right (**R**) side of your Walkman for longer than 2 seconds to skip to the beginning of the previous/next folder/playlist/album.
Skips to the beginning of the previous/next folder/playlist/album.
When skipping to the next folder/playlist/album, the voice guidance “Next folder,” “Next playlist,” or “Next album” are heard. When skipping to the previous folder/playlist/album, the voice guidance “Previous folder,” “Previous playlist,” or “Previous album” are heard.

Related Topic

- [Playing music](#)
- [Skipping to the previous/next song](#)




Digital Music Player

NWZ-WS613/WS615

Shuffle playback

Play songs in random order. The playback range of songs can be changed.



1. Press the button () on the left () side of your Walkman repeatedly.

Each time you press the button (), the voice guidance is heard and the playback mode changes in the order of **Normal**, **Repeat**, **Shuffle**, and **Normal**.

Note

- You cannot change the playback mode when you listen to music on the other Bluetooth audio device in Headphones Mode.

Related Topic


- [Playing music](#)
- [Repeat playback](#)
- [Changing the playback order to Folder Play/Playlist Play/Album Play](#)



Digital Music Player
NWZ-WS613/WS615

Repeat playback

Play songs repeatedly. The playback range of songs can be changed.



1. Press the button (1) on the left (L) side of your Walkman repeatedly.
Each time you press the button (1), the voice guidance is heard and the playback mode changes in the order of **Normal**, **Repeat**, **Shuffle**, and **Normal**.

Note

- You cannot change the playback mode when you listen to music on the other Bluetooth audio device in Headphones Mode.

Related Topic


- [Playing music](#)
- [Shuffle playback](#)
- [Changing the playback order to Folder Play/Playlist Play/Album Play](#)



Digital Music Player
NWZ-WS613/WS615

Changing the playback order to Folder Play/Playlist Play/Album Play

You can change the playback order to Folder Play/Playlist Play/Album Play. Default setting is for all songs to be played.



1. Press and hold the button (1) on the left (L) side of your Walkman repeatedly.
Each time you press and hold the button (1), the playback order changes as follows and voice guidance is heard.
 - **Folder (Normal)**
Plays songs in the order set in folders. Folders are groups of songs shown in Windows Explorer or the Mac Finder.
 - **Playlist**
Plays songs in the order set in playlists. Playlists are lists of songs to play back in a desired order created by using software such as Media Go (supplied) or Content Transfer.
 - **Album**
Plays songs in the order set in albums. Albums are groups of songs organized based on album information.

Note

- You cannot change the playback mode when you listen to music on the other Bluetooth audio device in Headphones Mode.

Related Topic


- [Playing music](#)
- [Shuffle playback](#)
- [Repeat playback](#)



Digital Music Player
NWZ-WS613/WS615

Limiting the volume

You can use AVLS (Automatic Volume Limiter System) to limit the maximum volume. This prevents the volume from getting too high and disturbing others, causing discomfort to your ears, or preventing you from hearing sounds around you, and it allows you to listen at a more comfortable volume.



1. Check that the playback is paused and the Bluetooth function is turned off.
2. Press and hold the Next button ([2]) on the right (R) side of your Walkman for about 5 seconds while pressing the button ([1]) on the left (L) side of the Walkman until the lamp ([3]) on the right (R) side of the Walkman lights up in orange.

The lamp ([3]) turns off when you release the Next button ([2]) and the button ([1]). The lamp ([3]) blinks in green twice and AVLS is set to on. The volume is kept to a moderate level.

To return the AVLS setting to off, repeat this step. When AVLS is set to off, the lamp ([3]) blinks in red twice.

Related Topic

- [Confirming the Walkman status by the OPR lamp](#)
- [Adjusting the volume](#)
- [Volume for calls on smartphones](#)
- [Volume operation \(Only for countries/areas complying with European and Korean Directives\)](#)



Deleting songs

To delete songs from your Walkman, use the software on your computer that you used to transfer the songs. If you used Windows Explorer to transfer the songs, use Windows Explorer to delete them. If you used the Finder on a Mac to transfer the songs, use the Finder on a Mac to delete the songs.

Hint

- Sample music is pre-installed on your Walkman. If you want to delete it, use the software.

Note

- Do not delete or rename the “MUSIC” folder. Otherwise, songs may not be recognized by your Walkman.

Related Topic

- [Deleting content from your Walkman using Media Go](#)
- [Deleting content from your Walkman using Content Transfer](#)
- [Deleting content from your Walkman using Explorer](#)
- [Deleting content from your Walkman using the Finder](#)



Digital Music Player

NWZ-WS613/WS615

What is the NFC function?

This function is for close-range wireless communication between various devices, such as mobile phones and IC tags. You can perform easy data communication simply by touching the devices together in the marked spot.

Related Topic

- [Connecting with a smartphone by the NFC function](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Requirements for smartphones connecting with your Walkman by one touch (NFC)

To connect with your Walkman by the NFC function, the system requirements of the smartphone are as follows.

NFC-compatible smartphones with Android 2.3.3 or later installed (excluding Android 3.X)

Hint

- If your smartphone is not NFC-compatible, connect with your Walkman using the Bluetooth function.

Note

- If your smartphone OS is Android 2.3.3 or later but prior to Android 4.1, you may need to download the “NFC Easy Connect” app. For details, refer to the operating instructions supplied with your smartphone.

Related Topic

- [Pairing and connecting with an Android smartphone](#)
- [Pairing and connecting with an iPhone](#)
- [Installing the “NFC Easy Connect” app on an Android smartphone](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

About “NFC Easy Connect”

The “NFC Easy Connect” app allows your smartphone to connect easily with the NFC-compatible devices manufactured by Sony. To find out more about the functions, search for “NFC Easy Connect” and download the free app. The app may not be available in some countries and/or regions.

Related Topic

● [Installing the “NFC Easy Connect” app on an Android smartphone](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Installing the “NFC Easy Connect” app on an Android smartphone

Download and install the “NFC Easy Connect” app on your Android smartphone.

1. Search for “NFC Easy Connect” at Google Play™ Store.
The app may not be downloadable in some countries/regions.
2. Install the “NFC Easy Connect” app on the smartphone by following the on-screen instructions.
3. Start the “NFC Easy Connect” app on the smartphone.
Make sure that the app screen is displayed.

Related Topic

- [Connecting with a smartphone by the NFC function](#)
- [Requirements for smartphones connecting with your Walkman by one touch \(NFC\)](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation




Digital Music Player


NWZ-WS613/WS615

Connecting with a smartphone by the NFC function

Simply touch your NFC-compatible smartphone to your Walkman to automatically turn on the power of the Walkman, pair the Walkman and the smartphone, and make a Bluetooth connection.



1. Make sure that your smartphone has the NFC function.
2. Activate the NFC function on your smartphone.
3. Touch the mark of your smartphone (1) to the mark on the right (R) side of your Walkman (2).
Unlock the screen of the smartphone beforehand. Keep touching the smartphone to the mark on your Walkman (2) until the smartphone responds.
4. Tap the confirmation screen on your smartphone.
Keep touching your smartphone to your Walkman until the connection is completed.



Your smartphone and your Walkman are paired and connected with each other. When the connection is made, the lamp (3) on the left (L) side of the Walkman blinks twice every 5 seconds.

Hint

- If your smartphone is in a case, the connection may not be made with one touch. Remove the case.
- If you have installed the “NFC Easy Connect” app on your smartphone, make sure that the screen of this app is displayed on the smartphone.
- The smartphone operations mentioned above are examples. Refer to the operating instructions of your smartphone for details.
- The procedure to tap the confirmation screen on your smartphone is required only the first time you make a one-touch connection.

Note

- If you touch your smartphone to the mark on your Walkman ([2]) while using the Remote Commander (supplied), the Remote Commander may be turned off. In this case, turn the Remote Commander on again.

Related Topic

- [Requirements for smartphones connecting with your Walkman by one touch \(NFC\)](#)
- [Pairing and connecting with an Android smartphone](#)
- [Pairing and connecting with an iPhone](#)
- [Disconnecting with the smartphone by the NFC function](#)

4-536-927-11(1)


Copyright 2014 Sony Corporation



Digital Music Player
NWZ-WS613/WS615

Disconnecting with the smartphone by the NFC function

Disconnect the connection between your Walkman and the smartphone by one touch.



1. Turn on the NFC function of your smartphone.
2. Touch your smartphone (1) to the mark on the right (R) side of your Walkman (2). Keep touching the devices together until messages appear on the screen of the smartphone.
When the connection is disconnected, a beep is heard and the lamp (3) on the left (L) side of your Walkman lights up for 2 seconds and then goes out.

Hint

- If your smartphone is in a case, the connection may not be disconnected with one touch. Remove the case.

Related Topic

- [Connecting with a smartphone by the NFC function](#)



Digital Music Player

NWZ-WS613/WS615

What is the Bluetooth function?

The Bluetooth function enables wireless data transfer between devices that support Bluetooth wireless technology. You can transfer data between these devices at a range of up to 10 meters in an open area.

You do not need to use a cable for connection, since the Bluetooth function uses wireless technology, nor is it necessary for the devices to face one another, as is the case with infrared technology. For example, you can use Bluetooth devices in a bag or pocket.

Related Topic

- [Turning the Bluetooth function on/off](#)
- [Notes on the Bluetooth function](#)

4-536-927-11(1)


Copyright 2014 Sony Corporation



Digital Music Player
NWZ-WS613/WS615

Turning the Bluetooth function on/off

Turn on the Bluetooth function of your Walkman and the smartphone when you pair them or connect the paired smartphone with the Walkman.



1. Press and hold the button (1) on the left (L) side of your Walkman for 2 seconds to turn the Bluetooth function on.


To turn off the Bluetooth function, press the button (1) again for 2 seconds.

Hint

- To reduce battery consumption, turn off the Bluetooth function when your Walkman is not connected to a smartphone.
- Headphones Mode is selected automatically when a Bluetooth audio device is connected to your Walkman. To switch the sound source and start Walkman Mode, press and hold the button (2) on the right (R) side of your Walkman until the voice guidance "Walkman Mode" is heard. At that time, the playback on the other Bluetooth device is stopped automatically.
- If the Bluetooth function is on when you turn off your Walkman, the Bluetooth function is turned on automatically the next time you turn on the Walkman.

Note

- The Bluetooth communications antenna is built in to your Walkman. If you cover the antenna (3) with your hands or other objects while using Bluetooth communications, the communication quality may be affected.



- Even if the Bluetooth function is turned off, only the Remote Commander can be connected to your Walkman.

Related Topic

- [Confirming the Bluetooth status by the Bluetooth lamp](#)
- [Connecting with a paired smartphone](#)
- [Playing music on a smartphone](#)
- [Pairing and connecting with an Android smartphone](#)
- [Pairing and connecting with an iPhone](#)

4-536-927-11(1)


Copyright 2014 Sony Corporation




Digital Music Player
NWZ-WS613/WS615

Pairing and connecting with an Android smartphone


When you connect your Walkman and smartphone for the first time, you need to pair them. Once pairing is successfully completed, future connections between them can be made with simple operations.



1. Check that your Walkman is turned on and the Bluetooth function is turned off.
If the Bluetooth function is turned on, press the button (1) on the left (L) side of your Walkman for 2 seconds to turn off.
2. Press and hold the button (1) for about 7 seconds.
3. Turn on the Bluetooth function on your smartphone.




4. Tap a menu (icon) to search for your Walkman on your smartphone.



Depending on the smartphone you use, the search may be started automatically.

5. Tap the model name of your Walkman.



If passkey input is required, input "0000." A Passkey may be called a "Pass code," a "PIN code," a "PIN number," or a "Password."

Your Walkman and the smartphone are paired to each other and a connection is made.

Hint

- If your smartphone has an NFC function, pairing and connection can be made with one touch.

Note

- Once pairing is successfully completed, you do not have to pair the devices again for future connections between them.
- Operations on smartphone mentioned above are examples. Refer to the operating instructions of your smartphone for details.
- If you pair your Walkman and a smartphone while using the Remote Commander, the Remote Commander is turned off. In this case, turn the Remote Commander on again.

Related Topic


- [Turning the Bluetooth function on/off](#)
- [Confirming the Bluetooth status by the Bluetooth lamp](#)
- [Playing music on a smartphone](#)
- [Connecting with a paired smartphone](#)
- [Connecting with a smartphone by the NFC function](#)



Digital Music Player
NWZ-WS613/WS615

Connecting with a paired smartphone

Connect a paired smartphone and your Walkman.



1. Press and hold the button (1) on the left (L) side of your Walkman for 2 seconds to turn on the Bluetooth function.

When the last paired smartphone is connected, a beep is heard and the lamp (2) on the left (L) side of your Walkman blinks twice every 5 seconds.

Hint

- When your Walkman is connected to the smartphone, the Walkman (model name) is shown as being connected in the Bluetooth settings screen of the smartphone. If the Walkman is not connected, tap the model name.
- To listen to music stored on your Walkman while connected to the smartphone, press and hold the button (3) on the right (R) side of your Walkman for 2 seconds to change the sound source.


Related Topic

- [Turning the Bluetooth function on/off](#)
- [Confirming the Bluetooth status by the Bluetooth lamp](#)
- [Playing music on a smartphone](#)
- [Pairing and connecting with an Android smartphone](#)
- [Pairing and connecting with an iPhone](#)
- [Connecting with a smartphone by the NFC function](#)
- [Selecting the sound source](#)

Digital Music Player
NWZ-WS613/WS615

Pairing and connecting with an iPhone

When you connect your Walkman and iPhone for the first time, you need to pair them. Once pairing is successfully completed, future connections between them can be made with simple operations.



1. Check that your Walkman is turned on and the Bluetooth function is not turned on.
If the Bluetooth function is turned on, press the button (1) on the left (L) side of your Walkman for 2 seconds to turn off.
2. Press and hold the button (1) for 7 seconds.
3. Turn on the Bluetooth function on your iPhone.



4. Tap the model name of your Walkman.



If passkey input is required, input “0000.” A Passkey may be called a “Pass code,” a “PIN code,” a “PIN number,” or a “Password.”

Your Walkman and the iPhone are paired to each other and a connection is made.

Note

- Once pairing is successfully completed, you do not have to pair the devices again for future connections between them.
- Operations on the iPhone mentioned above are examples. Refer to the operating instructions of your iPhone for details.
- If you pair your Walkman and a smartphone while using the Remote Commander, the Remote Commander is turned off. In this case, turn the Remote Commander on again.


Related Topic

- [Turning the Bluetooth function on/off](#)
- [Confirming the Bluetooth status by the Bluetooth lamp](#)
- [Playing music on a smartphone](#)
- [Connecting with a paired smartphone](#)

Digital Music Player
NWZ-WS613/WS615

Setting wireless playback quality

You can set whether to prioritize the sound quality or the stability of the connection.



1. Press and hold the button (1) on the right (R) side of your Walkman for 3 seconds to turn the Walkman off.
2. To change the sound quality setting, press and hold the button (1) while pressing the button (2 or 3) on the left (L) side of your Walkman for 5 seconds until the Walkman turns on.
Each time you perform the above operation, the sound quality setting changes as follows.

- **Prioritize connection**

The lamp (4) on the left (L) side of your Walkman blinks in blue once.

- **Standard**

The lamp (4) blinks in blue twice.

- **Prioritize sound quality**

The lamp (4) blinks in blue three times.

Prioritize connection

The sound quality may not be as good as the other mode, but the connection status will most likely be stable. This setting is recommended if the connection is unstable.

Standard

Stabilizes both connection and sound quality.

Prioritize sound quality

Sound is sent in high quality, but the connection may become unstable.

Hint

- Select prioritize sound quality to play songs with aptX/AAC Codec.

Note

- Changing the wireless playback quality setting of your Walkman may not have any effect depending on the settings of the smartphone.

Related Topic

- [Turning the Bluetooth function on/off](#)
- [Playing music on a smartphone](#)
- [Playing music](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Notes on the Bluetooth function

- Bluetooth wireless technology allows connection at a distance of up to about 10 meters. However, the effective range may vary depending on obstructions (people, metals, walls, etc.) or signal status.
- The Bluetooth antenna (aerial) is built into your Walkman and the Remote Commander. You can improve the sensitivity of Bluetooth communications by turning the built-in Bluetooth antenna (aerial) in the direction of the connected Bluetooth device. The communication distance shortens if there are obstructions between the connected device and the Walkman.
- The following conditions may cause noise, breakup of sound, changes in playback speed, or inoperability by the Remote Commander.
 - When using inside a metal bag.
 - When using inside a backpack or shoulder bag.
 - When using in an area with a wireless LAN, in an area where devices such as microwave ovens, mobile phones and mobile gaming devices with a communication function are in use nearby, or in other areas where electromagnetic waves are being emitted.
 - When the antenna (aerial) built into your Walkman or the Remote Commander is covered by your hand or blocked by people in situations such as riding in a crowded train.
- Because Bluetooth and wireless LAN (IEEE802.11b/g) devices use the same frequency (2.4 GHz), signal interference may occur, resulting in communication speed decrease, noise, or inability to connect, if Bluetooth communications are used near a wireless LAN device. In such cases, take the following measures.
 - Perform Bluetooth communications at least 10 meters away from the wireless LAN device when connecting your Walkman and a Bluetooth device.
 - Place your Walkman and the Bluetooth device as close together as possible.
 - Turn off the wireless LAN device when performing Bluetooth communications within about 10 meters of a wireless LAN device.
- Due to a characteristic of Bluetooth wireless technology, the sound played on the receiving Bluetooth device lags slightly behind the sound of the sending device.
- Radio waves emitted from a Bluetooth device may affect the operation of equipment such as electronic medical devices. Turn off your Walkman and other Bluetooth devices in the following locations as failure to do so may cause an accident.
 - In hospitals, near priority seats on trains, in airplanes, in places such as gasoline stations where flammable gases are present, near automatic doors or fire alarms
- Your Walkman supports security functions that comply with the Bluetooth standard to provide a secure connection when Bluetooth technology is used, but security may not be sufficient depending on the settings. Be careful when connecting using Bluetooth technology.
- Sony bears no responsibility whatsoever for information leaks that occur as a result of using Bluetooth technology.
- Your Walkman is not guaranteed to connect with all Bluetooth devices.

- Bluetooth devices you connect to must conform to the Bluetooth standard specified by Bluetooth SIG and be certified.
- Even if the connected device conforms to the above-mentioned Bluetooth standard, some devices may not be connected or work correctly depending on the features or specifications of the device.
- Depending on the device to be connected, the Bluetooth connection may take some time to be established.

Related Topic

● [Parts and controls](#)


4-536-927-11(1)

Copyright 2014 Sony Corporation

Digital Music Player
NWZ-WS613/WS615

Playing music on a smartphone

Play music on your smartphone that is connected to your Walkman via a Bluetooth connection.



1. Press the button (1) on the right (R) side of your Walkman for 3 seconds to turn on your Walkman.
2. Press and hold the button (2) on the left (L) side of your Walkman for 2 seconds to turn the Bluetooth function on.
The lamp (4) on the left (L) side of your Walkman blinks in blue and the last connected smartphone is connected.
3. Press the button (3) on the right (R) side of your Walkman to play a song.
Playback of music on the smartphone starts. To pause playback, press the button (3).

Note

- Music may not be played through the operation on your Walkman depending on the smartphone you use. If this occurs, operate on the smartphone.
- If the Bluetooth function is on when you turn off your Walkman, the Bluetooth function is turned on automatically the next time you turn on the Walkman.

Related Topic

- [Turning the Bluetooth function on/off](#)
- [Confirming the Bluetooth status by the Bluetooth lamp](#)
- [Pairing and connecting with an Android smartphone](#)
- [Connecting with a paired smartphone](#)
- [Pairing and connecting with an iPhone](#)

- Answering/hanging up a call
- Setting wireless playback quality

4-536-927-11(1)


Copyright 2014 Sony Corporation



Digital Music Player
NWZ-WS613/WS615

Answering/hanging up a call

You can answer and hang up a phone call to your smartphone that is connected to your Walkman via a Bluetooth connection.



1. Press the button (1) on the right (R) side of your Walkman to answer a call.
2. Press the button (1) to hang up the call.

Hint

- To reject an incoming call, press and hold the button (1) for 2 seconds while receiving a call.
- If you answer a call during music playback, playback is paused. Playback is resumed when you hang up the call.

Note

- Do not cover the microphone part (2) on the right (R) side of your Walkman with your hands or other object when you talk on your Walkman.

Related Topic


- [Volume for calls on smartphones](#)
- [Rejecting an incoming call](#)



Digital Music Player
NWZ-WS613/WS615

Rejecting an incoming call

When your Walkman is connected to your smartphone, you can reject an incoming call with the Walkman.



1. Press and hold the button () on the right () side of your Walkman for 2 seconds while receiving a call.

Hint

- If you answer a call during music playback, playback is paused. Playback is resumed when you hang up the call.

Related Topic

- [Answering/hanging up a call](#)

Digital Music Player
NWZ-WS613/WS615

Volume for calls on smartphones

The volume for music and the volume for calls are independent from each other. You can adjust the volume for calls during an incoming call or while talking on the phone. When you hang up the call, the volume returns to the level that was previously set for music.

The volume for calls is also kept to a moderate level if the AVLS is on.

Related Topic

- [Answering/hanging up a call](#)
- [Limiting the volume](#)




Digital Music Player

NWZ-WS613/WS615

Selecting the sound source

When your Walkman is connected to a Bluetooth audio device, you can select the sound source setting from between Walkman Mode and Headphones Mode.



1. Press and hold the button (**1**) on the right (**R**) side of your Walkman until the voice guidance “Walkman Mode” or “Headphones Mode” is heard.

Walkman Mode

Play back music on your Walkman.

Headphones Mode

Listen to music on a Bluetooth audio device with your Walkman.

Note

- Headphones Mode is selected automatically when a Bluetooth audio device is connected to your Walkman.
- If the Bluetooth function is on when you turn off your Walkman, the Bluetooth function is turned on automatically the next time you turn on the Walkman.


Hint

- When you change the sound source setting from Headphones Mode to Walkman Mode, the playback on the Bluetooth audio device is stopped automatically.
- The sound source setting may be changed by the SongPal settings. For details about how to use SongPal, refer to the help of SongPal.

Digital Music Player
NWZ-WS613/WS615

Using “Sound Mix”

When your Walkman is in Walkman Mode, “Sound Mix” allows you to listen to sound from smartphone applications and the Walkman at the same time.



1. Press and hold the button (1) on the right (R) side of your Walkman and the button (2) on the left (L) side of the Walkman until the voice guidance “Mix On” is heard.
To quit “Sound Mix,” press and hold the button (1) and the button (2) again until the voice guidance “Mix Off” is heard.

Hint

- You can also change the “Sound Mix” setting using SongPal. For details about how to use SongPal, refer to the help of SongPal.

Related Topic

[Selecting the sound source](#)



Digital Music Player

NWZ-WS613/WS615

What is SongPal?

SongPal is an application for controlling the audio devices manufactured by Sony that are compatible with SongPal from your smartphone. SongPal allows you to select music and start playback on your Walkman, or change various settings of the Walkman such as the playback mode or sound settings. For details on SongPal, visit the following website.

<http://rd1.sony.net/help/speaker/songpal/>

Related Topic

- [Installing SongPal on a smartphone](#)
- [Using SongPal](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player
NWZ-WS613/WS615

Installing SongPal on a smartphone

Download and install SongPal (version 2.0 or later) on your Android smartphone or iPhone to control your Walkman.

1. Search for “SongPal” at Google Play Store or App Store.
The app may not be downloadable in some countries/regions.
2. Install SongPal on your smartphone by following the on-screen instructions.

Related Topic

 [Using SongPal](#)



Digital Music Player

NWZ-WS613/WS615

Using SongPal

Use SongPal to control your Walkman from your smartphone.

1. Connect your Walkman to your smartphone via a Bluetooth connection.
2. On your smartphone, tap  and start SongPal.
The Home screen of SongPal is displayed on your smartphone.

Hint

- If the Home screen of SongPal is not displayed, flick the left end of the screen to the right and tap "Device Settings" - "Walkman (model name)" from Drawer of SongPal.

Note

- Use a smartphone that is compatible with the SPP Bluetooth profile.
- Depending on the smartphone you use, SongPal may start automatically.

Related Topic

- [Connecting with a smartphone by the NFC function](#)
- [Pairing and connecting with an Android smartphone](#)
- [Pairing and connecting with an iPhone](#)
- [Playing music on your Walkman by SongPal](#)
- [Changing the playback mode of your Walkman from SongPal](#)
- [Customizing the settings of your Walkman from SongPal](#)




Digital Music Player

NWZ-WS613/WS615

Home screen of SongPal

The following items are displayed on the Home screen of SongPal.



1. Home screen

Displays the functions of the selected device, music services, etc., allowing you to select an item by tapping. Shortcuts to the applications installed on your smartphone can also be placed on the Home screen.

Related Topic


- [Using SongPal](#)
- [Drawer of SongPal](#)



Digital Music Player NWZ-WS613/WS615

Drawer of SongPal

The following items are displayed in Drawer of SongPal. You can display Drawer of SongPal by flicking right on any SongPal screens.



1. Connected devices
Allows you to select a device that is compatible with SongPal.
2. Settings of the connected audio devices
Displays various sound settings, network settings, etc.

Note

- The screen shown above is an example, and may differ from the actual screen.

Related Topic

- [Using SongPal](#)
- [Home screen of SongPal](#)




Digital Music Player
NWZ-WS613/WS615

Playing music on your Walkman by SongPal


Use SongPal to play music on your Walkman using your smartphone.

1. From the Home screen of SongPal, select “Music.”




Depending on the smartphone you use, the “WALKMAN” functions may be displayed on the Home screen. Select “Music” to operate the Walkman.

2. Select the desired search method (“Folder,” “Playlists,” or “Album”) and items until the desired song is displayed.



3. Select the song you want to play.
The music playback screen is displayed and playback starts.



Note

- The selected search method is kept even after the Bluetooth connection to your smartphone is disconnected.
- The cover art images displayed on the SongPal screen are obtained from online services and may differ from the actual cover art.

Related Topic

[Using SongPal](#)




Digital Music Player
NWZ-WS613/WS615


Changing the playback mode of your Walkman from SongPal

Use SongPal to change the playback mode of your Walkman from your smartphone.

1. Tap the playback mode indication on the playback screen.



2. Select the desired playback mode.



Note

- The selected playback mode is kept even after the Bluetooth connection to your smartphone is disconnected.

Related Topic

● [Using SongPal](#)




Digital Music Player NWZ-WS613/WS615

Customizing the settings of your Walkman from SongPal

Customize various settings of your Walkman using SongPal.

1. Flick right on the SongPal screen to display Drawer of SongPal.



2. Select the desired item - desired setting.

Sound Settings

- Equalizer
 - Select Equalizer:
You can set the sound quality according to the music genre.
 - Edit Custom (available only when “Custom 1” or “Custom 2” is selected):
You can set CLEAR BASS and the 5 band equalizer. CLEAR BASS allows your Walkman to reproduce dynamic deep bass without distortion, even at a high volume.
- Clear Phase™
 - “Clear Phase™ ” optimizes the sound characteristics for the headphones.
- Dynamic Normalizer
 - You can moderate the volume between songs to minimize the differences in volume level.
- Sound Mix
 - You can turn “Sound Mix” on or off.

Power Settings

Battery

- You can check the remaining battery power of your Walkman.

Note

- Sound settings other than “Sound Mix” cannot be controlled on your Walkman. Use SongPal to change these settings. When you reset the Walkman to factory default, all settings return to the factory defaults.

Related Topic

- [Using SongPal](#)
- [Using “Sound Mix”](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Notes on handling your Walkman

Warning

- Be sure not to short-circuit the terminals of your Walkman with metallic objects.
- Do not put any foreign object in the Walkman. Doing so may cause fire or electric shock. If this occurs, turn off the Walkman immediately, disconnect the Walkman from your computer, and consult your nearest Sony dealer or Sony Service Center.
- Do not place your Walkman in fire.
- Do not take apart or modify your Walkman. Doing so can result in electric shock. Consult your nearest Sony dealer or Sony Service Center for exchange of rechargeable batteries, internal checks, or repair.
- Do not put any heavy object on top of your Walkman or apply a strong shock to it.
This may cause malfunction or damage.

The following descriptions are important for using your Walkman. Be sure to follow the instructions below.

- Charging time differs depending on battery usage conditions.
- If the battery life is reduced to about half of its normal life even if sufficiently charged, it has probably worn out. Please contact your nearest Sony dealer.
- Do not touch the rechargeable battery with bare hands if it is leaking. Consult your nearest Sony dealer if the battery has leaked as battery liquid may remain in your Walkman. If the liquid gets into your eyes, do not rub your eyes as this may lead to blindness. Wash out your eyes with clean water and consult a doctor.
If the liquid gets onto your body or clothes, wash it off immediately. Failure to do so may cause burns or injury. Consult a doctor if you are burned or injured by the liquid from the battery.
- Heat may build up in your Walkman while charging if it is used for an extended period of time.
- Note that condensation may form temporarily in cases such as when your Walkman is moved quickly from a low-temperature environment to a high-temperature environment, or used in a room where a heater has just been turned on. Condensation is a phenomenon where moisture in the air adheres to surfaces such as metal panels and then changes to liquid. If condensation forms in the Walkman, leave it turned off until the condensation disappears. If you use the Walkman with condensation present, a malfunction may result.
- If your Walkman causes interference to radio or television reception, turn the Walkman off and move it away from the radio or television.
- Mild tingling may be felt on your ears in particularly dry air conditions. This is a result of static electricity accumulated in the body, and it is not a malfunction of your Walkman.
This effect can be minimized by wearing clothes made from natural materials.
- Refrain from using your Walkman as is requested by in-flight announcements during takeoff or landing in an aircraft.
- If you see lightning or hear thunder, take off the headphones immediately and refrain from using your Walkman.
- Never use your Walkman where it will be subjected to extreme light, temperatures, humidity or vibration. For example, never leave the Walkman in a car parked in the sun or in direct sunlight. It may become discolored, distorted or

damaged.

- Do not leave your Walkman in a place subject to excessive dust.
- Do not leave your Walkman on an unstable surface or in an inclined position.
- Be sure to follow the precautions below when using your Walkman. Failure to do so may warp the casing or cause the Walkman to malfunction.
 - Do not sit down with your Walkman in your back pocket.



- If tanning oil or sunscreen gets onto your Walkman, wash it off using lukewarm water. Otherwise, it may cause discoloration or damage such as cracks to occur.
- Sample data is pre-installed on your Walkman.
- Sample data is not installed in some countries/regions.
- If you delete the sample data, you cannot restore it, and we will not supply any replacement data.
- Sony is not responsible for incomplete recording/downloading or damaged data due to problems with your Walkman or computer.

4-536-927-11(1)

Copyright 2014 Sony Corporation



Notes on headphones

Road safety

Avoid listening with your headphones in situations where hearing must not be impaired.

Preventing hearing damage

Avoid using the headphones at a high volume. Hearing experts advise against continuous, loud, and extended play. If you experience a ringing in your ears, reduce the volume or discontinue use.

Do not turn the volume up high all at once, especially when using headphones. Turn up the volume gradually to avoid excessive levels hurting your ears.

Consideration for others

Keep the volume at a moderate level. This will allow you to hear outside sounds and to be considerate to the people around you.

About the in-ear headphones

The earbuds seal your ears. Therefore, be aware that there is a risk of damage to your ears or eardrums if strong pressure is applied to the earbuds or the earbuds are suddenly removed from your ears. After use, be sure to take the earbuds off your ears gently.



Digital Music Player

NWZ-WS613/WS615

Notes on the software

- Copyright laws prohibit reproducing the software or the manual accompanying it, in whole or in part, or renting the software without the permission of the copyright holder.
- In no event will Sony be liable for any financial damage or loss of profits, including claims made by third parties, arising out of the use of the supplied software.
- The supplied software cannot be used with equipment other than that to which it is designated.
- Please note that, due to continued efforts to improve quality, the software specifications may be changed without notice.
- Operation of your Walkman with software other than that supplied is not covered by the warranty.
- The explanations in this manual assume that you are familiar with the basic operations of your computer.
For details on the use of your computer and operating system, please refer to the respective manuals.

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Maintenance of your Walkman

- Clean your Walkman with a soft cloth, such as a cleaning cloth for eyeglasses.
- Should your Walkman become excessively dirty, clean it with a soft cloth slightly moistened with water or mild detergent solution.
- Do not use any type of abrasive pad, scouring powder, or solvent such as alcohol or benzene as doing so may damage the surface of your Walkman.


Maintenance after swimming

Clean the earbuds and your Walkman after every use as follows.

The buildup of foreign substances such as earwax in the headphone sections may cause deteriorated sound quality or sound loss. If there is a buildup of any foreign substances on the terminals, your Walkman may not be charged or may not be recognized by your computer.


Wash the earbuds

Remove the earbuds and wash the earbuds by hand using a mild detergent solution. After washing the earbuds, dry them well.



Wash your Walkman

Do not rub foreign substances on the mesh sheet (1). Doing so may push them into the headphones.




Rinse the terminals (2) and mesh sheet (1) of your Walkman with gentle running tap water.



If the terminals (2) and mesh sheet (1) are not clean, wet a soft brush such as a toothbrush with water and clean them. Do not apply strong force to the mesh sheet (1). Doing so may damage the mesh sheet (1).

Wipe the moisture off the terminals and surface of your Walkman using a soft, dry cloth.

Pat the headphones softly against a dry cloth. Repeat patting about 20 times. Then place a dry cloth under the headphones and leave at room temperature for 2 to 3 hours.



4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player
NWZ-WS613/WS615

Customer support website

If you have any questions or issues with your Walkman, or would like information on compatible items with the Walkman, visit one of the following websites.

For customers in the USA:

<http://www.sony.com/walkmansupport>

For customers in Canada:

English

<http://www.sony.ca/ElectronicsSupport/>

French

<http://www.sony.ca/ElectronicsSupport/>

For customers in Latin America:

<http://www.sony-latin.com/index.crp>

For customers in Europe:

<http://www.sony.eu/dna/wm/>

For customers in Asia/Oceania/Middle East/Africa:

English

<http://www.sony-asia.com/support>

Korean

<https://scs.sony.co.kr/scs/handler/ProductSupport>

Simplified Chinese

<http://service.sony.com.cn/KB/>

Traditional Chinese

<http://service.sony.com.tw/>

For customers who purchased the overseas models:

<http://www.sony.co.jp/overseas/support/>



Digital Music Player

NWZ-WS613/WS615

Specifications

Interface

USB

Hi-Speed USB (USB 2.0 compliant)

Bluetooth

Bluetooth Specifications

- Communication system: Bluetooth specification version 4.0
- Output: Bluetooth specification Power Class 2
- Maximum communication range: Line of sight approx. 10 meters (30 feet) (*1)
- Frequency band: 2.4 GHz band (2.4000 GHz - 2.4835 GHz)
- Compatible Bluetooth profiles (*2)
 - A2DP (Advanced Audio Distribution Profile)
 - AVRCP (Audio Video Remote Control Profile)
 - HFP/HSP (Hands Free Profile/Headset Profile)
 - SPP (Serial Port Profile)
- Supported Codec (*3): SBC (*4)/AAC/aptX

Compatible iPhone/iPod models

Bluetooth technology works with iPhone 5s, iPhone 5c, iPhone 5, iPhone 4s, iPhone 4, iPhone 3GS, and iPod touch (4th and 5th generation).

Microphone

Monaural

Output (headphones)

Frequency response

20 Hz to 20,000 Hz (when playing data file, single signal measurement)

Sound Effects (*5)

- 5 Band equalizer (None/[Heavy]/[Pop]/[Jazz]/[Unique]/[Custom 1]/[Custom 2]) & CLEAR BASS
- [Clear Phase™] (On/Off)
- [Dynamic Normalizer] (On/Off)

Power Source

Built-in Rechargeable lithium-ion Battery

USB power (from a computer via a USB Cradle of the player)

Charging Time

USB-based charging

Approx. 1.5 hours

Quick charge

Approx. 3 minutes charge enables up to approx. 60 minutes playback.

Operating temperature

5 °C to 35 °C (41 °F to 95 °F)

Mass

Approx. 37 g (1.4 oz)

Water resistance

IPX5/IPX8 (IEC 60529) or equivalent (with Swimming earbuds attached)

Capacity (User available capacity) (*6)

NWZ-WS613: 4 GB

NWZ-WS615: 16 GB

Remote Commander

Bluetooth Specifications

- Communication system: Bluetooth specification version 4.0
- Output: Bluetooth specification Power Class 2
- Maximum communication range: Line of sight approx. 10 meters (30 feet) (*1)
- Frequency band: 2.4 GHz band (2.4000 GHz - 2.4835 GHz)

Power Source

CR1620 Lithium Coin Cell Battery (*7)

Operating temperature

5 °C to 35 °C (41 °F to 95 °F)

Mass

Approx. 11 g (0.4 oz)

Water resistance

IPX5 (IEC 60529) or equivalent

(*1) The range may vary depending on the communication environment.

(*2) Bluetooth profiles are standardized according to the purpose of the Bluetooth device.

(*3) Codec indicates the audio signal compression and conversion format.

(*4) SBC stands for Subband Codec.

(*5) The sound effects are available only when using SongPal.

(*6) Available capacity may vary. A portion of the memory is used for data management functions.

(*7) The battery supplied at the time of purchase may have a shorter battery life as it is installed at the factory to check the performance.

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Battery life

The time below may differ depending on ambient temperature or the status of use.

Battery life of your Walkman (continuous playback)

Actual battery life may vary depending on settings. The estimated battery usage hours shown below are based on typical usage conditions with “Settings of your Walkman for battery life measurement” as shown below.

Walkman Mode

MP3 128 kbps: approx. 8 Hrs

Linear PCM 1,411 kbps: approx. 7 Hrs

Headphones Mode

approx. 4 Hrs

Note

- Even if the player is turned off for an extended period, a small amount of battery power is still consumed.
- Battery life may vary depending on volume setting, conditions of use and ambient temperature.

Settings of your Walkman for battery life measurement

Music Settings

Equalizer (*1): OFF (default setting: OFF)

Dynamic Normalizer (*2): OFF (default setting: OFF)

Clear Phase™ (*3): OFF (default setting: OFF)

Bluetooth Settings

Wireless Playback Quality: Standard (default setting: Prioritize connection)

Sound Mix (*4): OFF (default setting: OFF)

Battery life of the Remote Commander

approx. 18 months (2 hours usage every day) (*5)

(*1) The [On] setting shortens the battery life about 25 % compared with the [Off] setting.

(*2) The [On] setting shortens the battery life about 30 % compared with the [Off] setting.

(*3) The [On] setting shortens the battery life about 60 % compared with the [Off] setting.

(*4) The [On] setting shortens the battery life about 35 % compared with the [Off] setting.

(*5) The battery life may differ depending on ambient temperature or the status of use. The value is for reference only.



Digital Music Player

NWZ-WS613/WS615

Maximum recordable number of songs and time (Approx.)

The approximate times are based on the case in which you transfer or record only 4 minute songs.

Number

NWZ-WS613

MP3 128 kbps: Approx. 940 songs

Linear PCM 1,411 kbps: Approx. 85 songs

NWZ-WS615

MP3 128 kbps: Approx. 3,900 songs

Linear PCM 1,411 kbps: Approx. 350 songs

Time

NWZ-WS613

MP3 128 kbps: Approx. 62 hr. 00 min.

Linear PCM 1,411 kbps: Approx. 5 hr. 40 min.

NWZ-WS615

MP3 128 kbps: Approx. 260 hr. 00 min.

Linear PCM 1,411 kbps: Approx. 23 hr. 20 min.



Digital Music Player

NWZ-WS613/WS615

Supported formats

Music (Music player)**Audio Formats****MP3**

Media File format: MP3 (MPEG-1 Layer3) file format

File extension: .mp3

Bit rate: 32 kbps to 320 kbps (Supports variable bit rate (VBR))

Sampling frequency (*1): 32, 44.1, 48 kHz

WMA (*2)

Media File format: ASF file format

File extension: .wma

Bit rate: 32 kbps to 192 kbps (Supports variable bit rate (VBR))

Sampling frequency (*1) : 44.1 kHz

Linear PCM

Media File format: Wave-Riff file format

File extension: .wav

Bit rate: 1,411 kbps

Sampling frequency (*1) : 44.1 kHz

AAC (*3)

Media File format: MP4 file format

File extension: .mp4, .m4a, .3gp

Bit rate: 16 kbps to 320 kbps (Supports variable bit rate (VBR)) (*4)

Sampling frequency (*1) : 8, 11.025, 12, 16, 22.05, 24, 32, 44.1, 48 kHz

(*1) Sampling frequency may not correspond to all encoders.

(*2) Copyright protected WMA files cannot be played back.

(*3) Copyright protected AAC-LC files cannot be played back.

(*4) Non-standard bit rates or non-guaranteed bit rates are included depending on the sampling frequency.



Digital Music Player

NWZ-WS613/WS615

System requirements

- Computer

- Windows Vista® Home Basic (Service Pack 2 or later)
- Windows Vista® Home Premium (Service Pack 2 or later)
- Windows Vista® Business (Service Pack 2 or later)
- Windows Vista® Ultimate (Service Pack 2 or later)
- Windows® 7 Starter (Service Pack 1 or later)
- Windows® 7 Home Basic (Service Pack 1 or later)
- Windows® 7 Home Premium (Service Pack 1 or later)
- Windows® 7 Professional (Service Pack 1 or later)
- Windows® 7 Ultimate (Service Pack 1 or later)
- Windows® 8
- Windows® 8 Pro
- Windows® 8.1
- Windows® 8.1 Pro
- Mac OS® X v10.6 or later

Pre-installed OS only supported.

“Compatibility mode” for Windows XP (included with Windows Vista and Windows 7) is not supported.

- CPU: 1 GHz processor (2.6 GHz recommended for video playback on PC)
- RAM: 1 GB or more (2 GB RAM required for Windows 8 64-bit)
- Hard Disk Drive/Solid State Drive: 600 MB or more of available space
- Web browser: Internet Explorer 7 or later
- Internet connection (for Gracenote® MusicID® service, podcast features, Store access, or online help)

Not supported by the following environments:

- Personally constructed computers or operating systems
- An environment that is an upgrade of the original manufacturer-installed operating system
- Multi-boot environment

We do not guarantee operation for all computers even if they meet the above System Requirements.



Digital Music Player

NWZ-WS613/WS615

Contents

List of accessories and manuals supplied with your Walkman.

- Walkman (1)
- Remote Commander (1)
- Earbuds (1 set)
- Swimming Earbuds (1 set)
- USB Cradle (1)
- Adjustment band (1)
- Holder (1)
- Quick Start Guide
- Using your Walkman while Swimming

Design and specifications are subject to change without notice.

Related Topic

- [About the differences between the two types of earbuds](#)
- [Changing the earbuds](#)
- [Using the Remote Commander](#)
- [How to store your Walkman in the carrying holder](#)

4-536-927-11(1)


Copyright 2014 Sony Corporation

Digital Music Player
NWZ-WS613/WS615

What can I do to solve a problem?

If your Walkman does not function as expected, try the following steps to resolve the issue.

Before resetting your Walkman, disconnect the Walkman from your computer and check that no content such as music is being played back. Otherwise, the data may be damaged. You can then reset the Walkman safely.



1. Check the topic on the issue in "Q&A."
2. Connect your Walkman to your computer to charge the battery.
You may be able to resolve some issues by charging the battery.
3. Press the button (1) on the right (R) side of your Walkman with a pen or a paper clip, etc. to reset your Walkman.
4. Check information on the issue in the help of the software having problems.
5. Look up information on the issue on one of the customer support websites.
6. If the approaches listed above fail to resolve the issue, consult your nearest Sony dealer.

Note

- Data will not be deleted, nor will any settings be changed by resetting.

Related Topic

- [Charging the battery](#)
- [Resetting your Walkman](#)
- [Customer support website](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Your Walkman does not operate or the power does not turn on.

- If you transfer a lot of content such as music to your Walkman at once, it will take time to build the database on the Walkman. Therefore, it will take more than 1 minute until the Walkman becomes operable again after you disconnect the Walkman from your computer. During this time, continuous beep sounds will be heard. Wait until beeping has stopped before you operate the Walkman.
- If your Walkman contains moisture condensation, wait a few hours to let the Walkman dry out.
- If the remaining battery power is low or insufficient, charge the battery.
- You cannot operate your Walkman while it is connected to a computer. Disconnect the Walkman from the computer.
- If your Walkman still does not operate after charging the battery, press the RESET button with a pen or a paper clip, etc., to reset the Walkman.

Related Topic

- [Charging the battery](#)
- [Resetting your Walkman](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Your Walkman does not work properly.

- Your Walkman may not work properly if the USB device (e.g. computer) to which it is connected is turned on or off without disconnecting the Walkman.

Reset your Walkman by pressing the RESET button with a pen or a paper clip, etc.

Related Topic

 [Resetting your Walkman](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Your Walkman power turns off or on automatically.

- If a malfunction occurs, your Walkman turns off and then on again automatically.

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

A drink (water, coffee, etc.) was spilled on your Walkman, or the Walkman was washed in the washing machine.

- If you spill a drink on your Walkman or wash it in a washing machine, liquid may get inside the Walkman. Stop using the Walkman immediately and consult your nearest Sony dealer.
- The water resistant performance of your Walkman is not applicable to liquids other than fresh water, tap water, perspiration, and pool water. If any liquid other than those mentioned gets on your Walkman, rinse it off with fresh water at room temperature or gently running tap water immediately and wipe the moisture off the Walkman using a soft dry cloth.

Sound may become muffled if water gets inside the headphones because the headphone sections are not water-tight. If water gets in the headphones, remove the water and do not use the Walkman until it dries completely.

Related Topic

- [Water resistant performance of this Walkman](#)
- [Liquids that the water resistant performance specifications apply to](#)
- [Customer support website](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

The earbuds supplied with the headphones are missing.

- If you lose or break the earbuds supplied with your headphones, please contact your nearest Sony dealer.

Related Topic

- [Changing the earbuds](#)
- [Changing the earbuds to Swimming earbuds](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

You want to back up the content such as music stored on your Walkman.

- Connect to a computer and copy the files onto the computer.
- If you have already deleted content transferred to your Walkman from Media Go, transfer the content from the Walkman to Media Go again.

Related Topic

- [Connecting to a computer](#)
- [Transferring content using Media Go](#)
- [Transferring content using Explorer](#)
- [Transferring content using the Finder](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

You want to find the product name (model name) of your Walkman.

- The model name is the alphabetical name starting with NW that is printed on the back of your Walkman. If the Walkman is inside a case, you need to remove it from the case to find the name.

Related Topic

- [Displaying your Walkman information](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

The voice guidance “Check the volume level” is heard.

- The voice guidance “Check the volume level” is meant to protect your ears when you turn the volume up to a level that is harmful for your ears for the first time. You can cancel the alarm and warning by pressing any button.
- You can turn up the volume after canceling the alarm and warning.
- After the initial warning, the alarm and warning repeat every 20 cumulative hours that the volume is set to a level that is harmful for your ears. When this happens, the volume is turned down automatically.

Related Topic

- [Volume operation \(Only for countries/areas complying with European and Korean Directives\)](#)
- [Adjusting the volume](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

There is no sound.

- Check that the volume level is not set to zero.
- If you are listening to music on a smartphone via a Bluetooth connection, check that the volume of the smartphone is not set to zero.
- If there is no sound from a smartphone when listening to music on the smartphone via a Bluetooth connection, the Bluetooth connection may not have been made. Check that the pairing for making a Bluetooth connection is completed and the smartphone is connected to your Walkman.
- If the problem persists after performing the remedies above, use a pen or paper clip, etc., to press the RESET button and reset your Walkman.

Related Topic

- [Playing music](#)
- [Playing music on a smartphone](#)
- [Resetting your Walkman](#)
- [Connecting with a paired smartphone](#)
- [Pairing and connecting with an Android smartphone](#)
- [Pairing and connecting with an iPhone](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Content such as music suddenly stops during playback.

- The remaining battery power is low or the battery has run out.
- The content may not be supported on your Walkman. Select and play other content.
- If you are playing music on a smartphone, check that your Walkman is connected to the smartphone.

Related Topic

- [Supported formats](#)
- [Connecting with a paired smartphone](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Noise is generated.

- The content such as music on your Walkman may be corrupted. Connect the Walkman to a Windows computer and use Media Go or Windows Explorer to delete the content in which the noise occurred from the Walkman. If you use a Mac computer, use the Finder to delete the corrupted content. After you have deleted the corrupted content, transfer the content from the computer to the Walkman again. Do not perform any other tasks on the computer while transferring content to the Walkman. Doing so may cause the content to be corrupted.
- Set the wireless playback quality to prioritize connection while listening to music stored on a smartphone.
- Set the wireless playback quality to prioritize sound quality while listening to music stored on your Walkman during a Bluetooth connection with a smartphone.

Related Topic

- [Setting wireless playback quality](#)
- [Deleting content from your Walkman using Media Go](#)
- [Deleting content from your Walkman using the Finder](#)
- [Deleting content from your Walkman using Explorer](#)
- [Transferring content using Media Go](#)
- [Transferring content using Explorer](#)
- [Transferring content using Content Transfer](#)
- [Transferring content using the Finder](#)



Digital Music Player

NWZ-WS613/WS615

Volume cannot be turned up, or the volume remains low when the playback volume is turned up.

- If the AVLS (Volume Limit) setting is activated, deactivate it.
- If the volume level cannot be adjusted on your Walkman when listening to music on a smartphone, increase the volume on the smartphone.

Related Topic

- [Adjusting the volume](#)
- [Limiting the volume](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Sound is interrupted or skips.

- The sound may be interrupted or skip depending on the environment where your Walkman is used or the settings of the Walkman.

Following the procedures below may reduce the amount of skipping or interruptions.

- Set all sound quality settings to off.
- Set the wireless playback quality to prioritize connection while listening to music stored on a smartphone.
- Set wireless playback quality to prioritize sound quality while listening to music stored on your Walkman during a Bluetooth connection with a smartphone.

If you are listening to music using the Bluetooth function, see “Notes on the Bluetooth function.”

Related Topic

- [Setting wireless playback quality](#)
- [Notes on the Bluetooth function](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

You cannot charge your Walkman.

- Charge the battery within the ambient temperature range of 5 °C to 35 °C (41 °F to 95 °F).
- You need to turn the computer power on in order to charge your Walkman. Check whether the computer is in standby (sleep) or hibernation status.
- Check that the USB connection to the computer is made properly.
- There may be bad electrical contact in the connector. Disconnect your Walkman, and then reconnect it.
- Use the supplied USB cable.
- Your Walkman may not be able to connect properly to your computer when using a USB hub. Connect the Walkman directly to a USB connector on your computer.
- Check whether the operating system and operating system version installed on the computer are compatible with your Walkman.
- The battery may have deteriorated if you have not used your Walkman for more than a year. Contact your nearest Sony dealer.
- If the remedies above do not solve the problem, use a pen or paper clip, etc. to press the RESET button and reset your Walkman, and then connect again using USB.

Related Topic

- [Charging the battery](#)
- [System requirements](#)
- [Resetting your Walkman](#)
- [Customer support website](#)



Digital Music Player

NWZ-WS613/WS615

How long is the life of the built-in rechargeable battery?

- This will differ depending on the environment where your Walkman is used, but on average the built-in rechargeable battery can be charged approximately 500 times. The battery life becomes shorter and capacity is reduced as a result of the number of times it is recharged or used, and the environment in which it is used. When the usable battery life is half the usual time even when the battery is fully charged, the battery should be replaced.
- Consult your nearest Sony dealer for more details on the life of the built-in battery.

Related Topic

 [Customer support website](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

The rechargeable battery needs to be replaced.

- To replace rechargeable batteries, your Walkman needs to be taken apart professionally. Do not take apart the Walkman by yourself.
- Consult your nearest Sony dealer or Sony Service Center for replacement of rechargeable batteries.

Related Topic

- [Replacing the battery of the Remote Commander](#)
- [Customer support website](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

The battery life is short.

- If your Walkman is used in an environment where the temperature is below 5 °C (41 °F), the battery life becomes shorter due to characteristics of the battery. This is not a malfunction.
- Charge the battery until it is full.
- More battery power is consumed when the Bluetooth function is used.
- You can preserve the battery life and get more use from each charge by changing your Walkman settings and managing the power appropriately.
- Depending on the environment in which your Walkman is used, the battery may deteriorate if it is not used for over a year. Contact your nearest Sony dealer.
- If the usable battery life is half that when new even after sufficiently charging the battery, your battery may have deteriorated. Contact your nearest Sony dealer.

Related Topic

- [Charging the battery](#)
- [Extending the battery life](#)
- [Customer support website](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

How long is the standard battery duration?

- For details on the battery duration, see “Battery life.”

Related Topic

 [Battery life](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation

Digital Music Player
NWZ-WS613/WS615

How long does it take to charge the battery?

- For details on the charging time, see “Specifications.”

Related Topic

● [Specifications](#)



Digital Music Player

NWZ-WS613/WS615

The computer does not recognize your Walkman.

- If the remaining battery power is low, charge the battery.
- When you use your Walkman for the first time, or if you have not used the Walkman for a long time, it may take a few minutes to be recognized by the computer. Check that the computer recognizes the Walkman after you have connected it to the computer for about 10 minutes.
- Make sure that the USB connection to the computer is made properly and securely.
- Use the supplied USB cable.
- Your Walkman may not be recognized if connected via a USB hub. Connect the Walkman directly to the USB connector on your computer.
- If the approaches listed above fail to resolve the issue, press the RESET button with a pen or a paper clip, etc., to reset your Walkman, and then try the USB connection again.

Related Topic

- [Charging the battery](#)
- [Connecting to a computer](#)
- [Resetting your Walkman](#)



Digital Music Player

NWZ-WS613/WS615

You cannot install software to your computer.

- Media Go can be also obtained by downloading it via the Internet. If you cannot find the “MediaGo_WM(.exe)” file or the installation does not start even though you double-clicked the file, download Media Go from the following website and install it by following the on-screen instructions. <http://mediago.sony.com/enu/>
- If other software is running, it may interfere with the installation. Be sure to quit all other software before installing this software. Particularly, be sure to disconnect from the Internet and quit security software as it can put a heavy load on the computer.
- There may not be enough free space on the hard drive. Check the amount of free hard drive space required to install the software, and then delete any unnecessary files.
- With a Windows computer, you may not be able to install the software if your account does not have administrator privileges or if you have not logged in as a computer administrator. Log in using an account with administrator privileges or as the computer's administrator. Furthermore, if two-byte characters are used in the user name, create a new account using only one-byte characters in the user name.
- With a Windows computer, a message dialog may be hidden by the install screen, making the install process seem stopped. Press and hold the “Alt” key while pressing the “Tab” key several times. When the dialog is displayed, follow the instructions in the dialog box.

Related Topic

- [System requirements](#)
- [Installing Media Go](#)
- [Installing Content Transfer](#)



Digital Music Player

NWZ-WS613/WS615

The progress bar on the install screen does not proceed while installing the software.

- Wait until the installation is completed, because it is progressing properly. Installation may take 30 minutes or more depending on the computer used.

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Your Walkman is not recognized by Media Go.

- Your Walkman may not be recognized by the computer. Disconnect the Walkman from the computer, and then reconnect it.
- The software may have failed to install correctly. Use the installer to re-install the software. The imported data will remain untouched.
- If the remedies above do not solve the problem, use a pen or paper clip, etc. to press the RESET button and reset your Walkman, and then connect again via USB.

Related Topic

- [Connecting to a computer](#)
- [Installing Media Go](#)
- [Resetting your Walkman](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Content such as music cannot be transferred from the computer to your Walkman.

- Check that the USB connection to the computer is made properly.
- Use the supplied USB cable.
- You may not be able to transfer content when using a USB hub. Connect directly to the USB connector on your computer.
- The version of the installed software may be earlier than that of the supplied Media Go. Install the supplied Media Go or the latest version through the Internet.
- There is not enough free space in your Walkman, or the number of files has exceeded the maximum number of transferable files. Delete any unnecessary content to increase free space. For details on the number of files recordable, see the following.
 - “Maximum recordable number of songs and time (Approx.)”
- Songs with a limited playing period or playing count may not be transferred due to restrictions set by copyright holders. For details on the settings of each audio file, contact the distributor.
- Some of the content on your Walkman may be damaged. Return required content to the computer and initialize (format) the Walkman.
- If the software is not compatible with your Walkman, install compatible software and use the compatible software to transfer content.
- You may be attempting to transfer corrupted content. Delete the content that cannot be transferred from the computer, and import this content to the computer again. Do not perform any other tasks on the computer when transferring content to your computer. Doing so may cause the content to be corrupted.
- You may be attempting to transfer a file that is not in playable format. See “Supported formats.”
- Transferring may be stopped due to noise such as static electricity accumulated in the computer. This happens to protect data. Disconnect your Walkman, and then reconnect it.

Related Topic

- [Connecting to a computer](#)
- [Installing Media Go](#)
- [Maximum recordable number of songs and time \(Approx.\)](#)
- [Supported formats](#)



Digital Music Player

NWZ-WS613/WS615

Only a small amount of content such as music can be transferred to your Walkman.

- There is not enough free memory space on your Walkman. Delete any unnecessary content to increase free space.
- If content that cannot be played on your Walkman is stored on the Walkman, less content can be transferred. Transfer content other than that which you want to play on the Walkman back to the computer in order to increase the available space.

Related Topic

- [Maximum recordable number of songs and time \(Approx.\)](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

You cannot play content such as music transferred to your Walkman.

- If the remaining battery power is low or insufficient, charge the battery. If your Walkman still does not operate after charging the battery, press the RESET button with a pen or a paper clip, etc. to reset the Walkman.
- The data hierarchy levels of the content such as music transferred by drag-and-drop may not be correct. Place them in the appropriate folder and hierarchy.
- Transferred files are not in a playable format. See “Supported formats” for details on playable formats.
- When you transfer audio MP4 files by drag-and-drop, place them in the “MUSIC” folder of your Walkman.
- The transferred content may be damaged. When you transfer content, make sure that no other tasks are running on your computer until transferring is completed. Otherwise, the content may be damaged. Delete the unplayable content from your Walkman and transfer it again. If the Walkman is still unable to play the content, format the built-in flash memory of the Walkman using the function of the Walkman and then transfer the content again.
- If you change the file names or location of the content such as music that was transferred from your computer to your Walkman, the content may not be recognized by the Walkman. Return it to the correct name and location.
- If you have initialized (formatted) the built-in flash memory of your Walkman using Windows Explorer, initialize (format) it again using the Walkman. If you have initialized (formatted) the Walkman using the Mac Finder, initialize (format) it again using the Walkman.

Related Topic

- [Charging the battery](#)
- [Resetting your Walkman](#)
- [Transferring content using Explorer](#)
- [Transferring content using the Finder](#)
- [Supported formats](#)
- [Deleting content from your Walkman using Media Go](#)
- [Deleting content from your Walkman using Explorer](#)
- [Deleting content from your Walkman using the Finder](#)
- [Formatting memory](#)
- [Notes for transferring content such as music from your computer](#)



Digital Music Player

NWZ-WS613/WS615

Songs are not played back in the expected order.

- If songs are being played back using shuffle, cancel shuffle to return to normal playback.
- When tracks are transferred from the computer using drag-and-drop, the track order may be different from the album track order. Create a playlist using software on your computer and transfer the playlist to your Walkman. For details on playlists, refer to the help of the software you are using.

Related Topic

- [Shuffle playback](#)
- [Transferring content using Media Go](#)
- [Transferring content using Content Transfer](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Sound becomes muffled when using your Walkman in water, such as when swimming.

- The headphone sections are not watertight, so the sound quality of your Walkman may deteriorate if water gets inside the headphones. If water gets in the headphones, remove the water and dry well before using again.
- Before swimming, attach the appropriate earbuds to prevent water from getting inside the headphones.

Related Topic

- [How the sound becomes muffled while you are swimming](#)
- [If the sound becomes muffled while swimming](#)
- [Changing the earbuds to Swimming earbuds](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

You dropped your Walkman in water.

- The headphone sections are not watertight, so the sound quality of your Walkman may deteriorate if water gets inside the headphones. If water gets in the headphones, remove the water and dry well before using again.

Related Topic

- [If the sound becomes muffled while swimming](#)
- [Maintenance of your Walkman](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

The headphones are not firmly seated on your ears.

- Place the headphone sections into your ears, and then adjust your Walkman so that it feels comfortable.

Related Topic

- [How to place your Walkman on your ears](#)
- [Improving the fit](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation

Digital Music Player
NWZ-WS613/WS615

The neckband part does not fit.

- Attach the adjustment band (supplied) to the neckband part, and then place your Walkman on your ears.

Related Topic

 [Improving the fit](#)



Digital Music Player

NWZ-WS613/WS615

The earbuds do not fit.

- Try earbuds of a different size.

Related Topic

- [Changing the earbuds](#)
- [Changing the earbuds to Swimming earbuds](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Pairing cannot be done.

- Pair the devices within the Bluetooth communications range.
- If the support profiles are different, your Walkman and smartphone cannot be paired. See "Specifications."
- Your Walkman cannot be paired if the number of paired smartphones exceeds the maximum number.
- Your Walkman works as a Bluetooth receiver and cannot connect with Bluetooth speakers or headphones as they also work as receivers.

Related Topic

- [Specifications](#)
- [Turning the Bluetooth function on/off](#)
- [Confirming the Bluetooth status by the Bluetooth lamp](#)
- [Connecting with a paired smartphone](#)
- [Pairing and connecting with an Android smartphone](#)
- [Pairing and connecting with an iPhone](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

You cannot connect via the Bluetooth function.

- Check that the Bluetooth function of your Walkman and smartphone are turned on.
- Check that the model name of your Walkman is selected in the Bluetooth connection screen of the smartphone. If not, tap the model name of the Walkman.
- Your Walkman cannot connect with a smartphone that is not paired. Check that the Walkman has been paired with the smartphone.
- The pairing information might have been deleted. Make the pairing operation again.
- If your Walkman and the smartphone are too far from each other, a Bluetooth connection may not be established or may be interrupted. Place the Walkman and the smartphone closer.

Related Topic

- [Turning the Bluetooth function on/off](#)
- [Confirming the Bluetooth status by the Bluetooth lamp](#)
- [Connecting with a paired smartphone](#)
- [Pairing and connecting with an Android smartphone](#)
- [Pairing and connecting with an iPhone](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

The screen to enter the passkey appears when pairing with a smartphone.

- The passkey on your Walkman is “0000.” Input “0000” on the smartphone.

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

Sound skips or noise is generated during a Bluetooth connection.

- Devices using the 2.4 GHz frequency, such as a wireless LAN device, cordless telephone, or microwave oven, may disturb the Bluetooth connection. Use your Walkman and connected smartphone away from these electronic devices.
- The Bluetooth connection is impeded by obstructions such as metal, walls or people. Remove any obstructions or change the location to enable proper communication.
- Set the wireless playback quality to prioritize sound quality while listening to music stored on your Walkman during a Bluetooth connection with a smartphone.
- The Bluetooth connection status becomes unstable depending on the combination of the bit rate settings of transmission to the connected Bluetooth audio device and the usage environment.
The Bluetooth connection may be stabilized by performing the following measures.
 - Set the wireless playback quality to prioritize connection.
- Set the wireless playback quality to prioritize connection while listening to music stored on the smartphone.

Related Topic

- [Setting wireless playback quality](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

You cannot connect with one touch (NFC).

- Make sure that the smartphone has the NFC function and the NFC function is enabled.
- Unlock the screen lock of the smartphone.
- When a dialog is displayed on the screen, follow the on-screen instructions to complete the connection. The operation may not have been completed on the smartphone. Tap the confirmation dialog displayed on the smartphone to complete the operation.
- If the smartphone does not recognize your Walkman, slowly move the smartphone in all directions with the N-mark touching over the N-mark on the Walkman.
- If a clip or case is attached to the device to connect with or to your Walkman, remove the clip or case.
- The NFC reception sensitivity of the device you use may be insufficient to make a one-touch connection (NFC). In this case, make the Bluetooth connection with pairing.
- One-touch connections (NFC) cannot be made while your Walkman is connected to a computer, as the Walkman is inoperable during those times. Disconnect all connections and try again.

Related Topic

- [Connecting with a smartphone by the NFC function](#)
- [Requirements for smartphones connecting with your Walkman by one touch \(NFC\)](#)
- [Pairing and connecting with an Android smartphone](#)
- [Pairing and connecting with an iPhone](#)



Digital Music Player

NWZ-WS613/WS615

You cannot hear sound from the connected smartphone.

- With some smartphones, the volume cannot be controlled by your Walkman. Turn up the volume on the smartphone.
- Check that content such as music is being played back on the music player application on the smartphone.
- Check that the pairing for making a Bluetooth connection is completed and the smartphone is connected to your Walkman.
- Even when your Walkman is connected to a smartphone via a Bluetooth connection, sound from the smartphone is not heard on the Walkman when the Walkman is in Walkman Mode. Change the sound source setting to Headphones Mode.

Related Topic

- [Connecting with a paired smartphone](#)
- [Pairing and connecting with an Android smartphone](#)
- [Pairing and connecting with an iPhone](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

You cannot take incoming calls properly.

- A Bluetooth connection may not have been made. Check that the pairing for making a Bluetooth connection is completed and the smartphone is connected to your Walkman.
- Do not cover the built-in microphone part with your hand.
- Check that your Walkman is turned on.
- Your Walkman cannot receive calls while it is connected to a computer or being charged.

Related Topic

- [Connecting with a paired smartphone](#)
- [Pairing and connecting with an Android smartphone](#)
- [Pairing and connecting with an iPhone](#)
- [Answering/hanging up a call](#)

4-536-927-11(1)

Copyright 2014 Sony Corporation



Digital Music Player

NWZ-WS613/WS615

You cannot operate your Walkman by the Remote Commander.

- Make sure that the Remote Commander (supplied) is turned on.
- Make sure that your Walkman is turned on.
- Reset the Remote Commander and your Walkman by following the procedures below.
 1. Press the **◀◀** and **▶▶** buttons of the Remote Commander at the same time and hold for about 10 seconds.
 2. Press the RESET button of your Walkman with a pen or a paper clip, etc.
 3. Turn on the Remote Commander and your Walkman.
- Pair the Remote Commander and your Walkman again by following the procedures below.
 1. Press the **◀◀** and **▶▶** buttons of the Remote Commander at the same time and hold for about 10 seconds.
 2. Turn on the Remote Commander.

The lamp of the Remote Commander blinks in red and blue alternately.
 3. Make sure that your Walkman is turned on and the Bluetooth function is turned off, and press and hold the **Ⓡ** button of the Walkman for about 7 seconds.

When pairing is successfully completed, the lamp of the Remote Commander blinks in blue.
- You cannot use the Remote Commander when it is wet. Dry the Remote Commander using a dry cloth.
- A device using the 2.4 GHz frequency, such as a wireless LAN device, Bluetooth audio device, or microwave oven, may disturb the Bluetooth connection. Use your Walkman and the connected Remote Commander away from these devices.
- The Bluetooth connection between your Walkman and the Remote Commander may be obstructed by, for example, metal, walls, or people. Remove any obstructions or change the location to enable proper communications.
- Replace the battery of the Remote Commander. See “Replacing the battery of the Remote Commander” for details.

Related Topic

- [Using the Remote Commander](#)
- [Replacing the battery of the Remote Commander](#)



Digital Music Player

NWZ-WS613/WS615

Your Walkman gets warm.

- Depending on the way you use your Walkman, the Walkman may become warm while the battery is being charged or the Walkman is performing intensive data processing. This is not a malfunction.

4-536-927-11(1)

Copyright 2014 Sony Corporation